

Industrial Automation Headquarters

Delta Electronics, Inc.

Taoyuan Technology Center
No.18, Xinglong Rd., Taoyuan City,
Taoyuan County 33068, Taiwan
TEL: 886-3-362-6301 / FAX: 886-3-371-6301

Asia

Delta Electronics (Jiangsu) Ltd.

Wujiang Plant 3
1688 Jiangxing East Road,
Wujiang Economic Development Zone
Wujiang City, Jiang Su Province, P.R.C. 215200
TEL: 86-512-6340-3008 / FAX: 86-769-6340-7290

Delta Greentech (China) Co., Ltd.

238 Min-Xia Road, Pudong District,
ShangHai, P.R.C. 201209
TEL: 86-21-58635678 / FAX: 86-21-58630003

Delta Electronics (Japan), Inc.

Tokyo Office
2-1-14 Minato-ku Shibadaimon,
Tokyo 105-0012, Japan
TEL: 81-3-5733-1111 / FAX: 81-3-5733-1211

Delta Electronics (Korea), Inc.

1511, Byucksan Digital Valley 6-cha, Gasan-dong,
Geumcheon-gu, Seoul, Korea, 153-704
TEL: 82-2-515-5303 / FAX: 82-2-515-5302

Delta Electronics Int'l (S) Pte Ltd.

4 Kaki Bukit Ave 1, #05-05, Singapore 417939
TEL: 65-6747-5155 / FAX: 65-6744-9228

Delta Electronics (India) Pvt. Ltd.

Plot No 43 Sector 35, HSIIDC
Gurgaon, PIN 122001, Haryana, India
TEL : 91-124-4874900 / FAX : 91-124-4874945

Americas

Delta Products Corporation (USA)

Raleigh Office
P.O. Box 12173, 5101 Davis Drive,
Research Triangle Park, NC 27709, U.S.A.
TEL: 1-919-767-3800 / FAX: 1-919-767-8080

Delta Greentech (Brasil) S.A.

Sao Paulo Office
Rua Itapeva, 26 - 3° andar Edifício Itapeva One-Bela Vista
01332-000-São Paulo-SP-Brazil
TEL: 55 11 3568-3855 / FAX: 55 11 3568-3865

Europe

Delta Electronics (Netherlands) B.V.

Eindhoven Office
De Witbogt 20, 5652 AG Eindhoven, The Netherlands
TEL : +31 (0)40-8003800 / FAX : +31 (0)40-8003898

DX-020BC20-02

2020-05-14

*We reserve the right to change the information in this manual without prior notice.



DX-2300 Series Industrial Ethernet Cloud Router User Manual

DIACloud Cloud Platform

DX-2300 Series Industrial Ethernet Cloud Router User Manual

Revision History

Version	Revision	Date
1 st	The first version was published.	2016/3/21
2 nd	<ol style="list-style-type: none"> 1. Add new functions featuring Auto Detect/ Target Address in section 3.2.1. 2. Add a new function featuring PHY Auto Reset in section 3.2.2. 3. Add a new function featuring Storm Filtering in section 3.2.3. 4. Add a new function featuring Remote Access Port in section 3.2.1. 5. Chapter 3: Add new function featuring Set Local PC Time in Section3.4.2. 6. Chapter 3: Update information concerning Transparent mode/ Slave mode/ Master mode/ Serial Server-TCP Server/ Serial Server-TCP Client/ Serial Server-UDP Client/ RS485 mode in Section3.4.3. 7. Chapter 3: Add new function featuring MC master mode in section 3.4.3. 8. Chapter 3: Update information concerning Transparent mode/ Slave mode/ Master mode/ Serial Server-TCP Server/ Serial Server-TCP Client/ Serial Server-UDP Client/ RS485 mode in Section 3.4.4. 9. Chapter 3: Add new function of Siemens TCP in section 3.4.6. 10. Chapter 3: Update information concerning functions of Diagnosing Method/ Host Name/IP Address in section 3.4.14. 11. Chapter 3: Add new function of Trouble shooting in section3.4.15. 12. Chapter 3: Add new function of Add/ Export Configure List/ Import Configure List/ Register Type/ Register Start Address in section 3.4.18. 13. Chapter 4: Update information concerning functions of PPI and add new function of Auto Baudrate. In section 4.2.2. 	2020/5/14

DX-2300 Series Industrial Ethernet Cloud Router User Manual

Table of Contents

Chapter 1 Introduction

1.1	Product Overview	1-3
1.1.1	Network Design	1-3
1.1.2	Features	1-4
1.1.3	Front Panel Ports and LEDs	1-5
1.1.4	Bottom Panel	1-5
1.1.5	Dimension	1-6
1.2	Package Checklist	1-7

Chapter 2 User Interface

2.1	Web-based GUI Configuration	2-2
2.1.1	System Connection	2-2
2.1.2	Default IP Address/Account/Password	2-2
2.1.3	Local Network Setups	2-2
2.1.4	Logging in	2-4
2.2	DIADevice	2-5
2.2.1	Device connection and detection	2-6
2.2.2	Network Setting	2-7
2.2.3	Bind Device	2-9
2.2.4	Open Device Webpage	2-11
2.3	Typical application configuration	2-5
2.3.1	Data Collection	2-12
2.3.2	Remote Debugging	2-18

Chapter 3 Functions

3.1	Status	3-3
3.1.1	Device Information	3-3
3.1.2	Network Status	3-4
3.1.3	Routing Table	3-5
3.1.4	Local Log	3-5
3.1.5	Traffic Statistics	3-6
3.1.6	Cloud Status	3-6
3.1.7	Connected Device	3-6
3.2	Network	3-7
3.2.1	WAN Configurations	3-7
3.2.2	LAN Configurations	3-9

3.2.3	Storm Filtering	3-11
3.2.4	Static Routing Rules	3-11
3.2.5	Dynamic DNS.....	3-13
3.3	Firewall	3-14
3.3.1	Firewall Settings.....	3-14
3.3.2	DMZ Settings	3-17
3.3.3	Port Forward	3-17
3.3.4	Port Trigger	3-20
3.3.5	URL Filter	3-21
3.3.6	MAC Filter	3-22
3.3.7	IP Filter	3-23
3.4	System	3-24
3.4.1	User Management.....	3-24
3.4.2	Time Zone Configurations	3-25
3.4.3	RS232	3-26
3.4.4	RS485	3-36
3.4.5	Modbus TCP.....	3-44
3.4.6	Siemens TCP.....	3-47
3.4.7	Log Settings	3-50
3.4.8	Firmware Upgrade	3-51
3.4.9	Backup & Restore	3-52
3.4.10	Scheduled Jobs	3-53
3.4.11	Add A New Job	3-53
3.4.12	Export Job List	3-54
3.4.13	Import Job List.....	3-54
3.4.14	Network Diagnosis.....	3-54
3.4.15	Trouble shooting.....	3-55
3.4.16	System Reboot.....	3-56
3.4.17	Event Management	3-56
3.4.18	Register Management.....	3-59
3.5	Cloud Service	3-60
3.5.1	Cloud Configurations	3-60
3.5.2	Proxy Setting	3-65
3.5.3	Secure Tunnel Firewall.....	3-66
3.5.4	Cloud Log	3-67
3.6	SD Card Quick Configuration	3-68

Chapter 4 DIACom

4.1	Introduction to DIACom.....	4-2
4.1.1	Select a Suitable Firmware Version.....	4-2

4.1.2	DIACom Installation.....	4-3
4.1.3	DIACloud Account Registration	4-3
4.1.4	Bind DIACloud Account	4-5
4.2	DIACom Operation.....	4-6
4.2.1	Setup a Secure Tunnel	4-6
4.2.2	Create a Virtual Serial-Port	4-10
4.2.3	Remote Control and Monitoring via DIACom	4-12
4.2.4	Automation Startup	4-14

Chapter 5 DIACloud

5.1	Introduction to DIACloud	5-2
5.1.1	Select a Suitable Firmware Version.....	5-2
5.2	Instructions for DIACloud	5-2
5.2.1	Register and Login	5-2
5.2.2	Home.....	5-4
5.2.3	Devices	5-6
5.2.4	Alarm	5-16
5.2.5	Secure Tunnels.....	5-16
5.2.6	Sub Users.....	5-18
5.2.7	Logs	5-21
5.2.8	Orders	5-22
5.2.9	Profile	5-23

Chapter 6 DIACloud APP

6.1	Introduction to DIACloud APP	6-2
6.1.1	Select a Suitable Firmware Version	6-2
6.1.2	DIACloud APP Installation.....	6-2
6.2	DIACloud APP Function.....	6-2
6.2.1	DIACloud APP Login	6-2
6.2.2	Device List	6-4
6.2.3	Device Details.....	6-5
6.2.4	Registers View	6-6
6.2.5	Alarm List	6-7

Chapter 1 Production Introduction

Table of Contents

- 1.1 Product Overview 1-3**
 - 1.1.1 Network Design 1-3
 - 1.1.2 Features 1-4
 - 1.1.3 Front Panel Ports and LEDs 1-5
 - 1.1.4 Bottom Panel 1-5
 - 1.1.5 Dimension 1-6
- 1.2 Package Checklist 1-7**

About This Manual

The user manual is suitable for **DX-2300LN-WW**. If you need to use the Delta DX-2300 series products in China areas, please refer to the model name **DX-2300LN-CN** on the Delta website, or contact our branch offices or distributors.

FCC Interference Statement

This equipment has been tested and found to comply with the limits for a class A digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates radio frequency signal and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

CE Declaration of Conformity

In accordance with the Directives 2004/108/EC*, 2014/30/EU, 2006/95/EC* and 2014/35/EU. The test record, data evaluation and DX-2300 Series configurations represented herein are true and accurate under the standards herein specified.

Disclaimers and Limitation of Liabilities

To the maximum extent permitted by law and regardless DELTA be aware or has been advised of the possibility of these damages, DELTA is not liable to any user or anyone else for: (a) any loss of use, data, reputation, goodwill, credit, opportunity, economy or profits, whether or not foreseeable; (b) any special, incidental, indirect, consequential, or punitive damages whatsoever; (c) any losses or damages based on any theory of liability, including breach of contract or warranty, negligence or other tortious action; (d) any losses or damages resulting from use or unable to use the systems or devices to which the Software or Services are incorporated or co-operated; and (e) any losses or damages arising from any other claim or in connection with the use of or access to the Software or Services.


1.1 Product Overview

The DX-2300LN-WW is a wired industrial router, an Internet of Things wired communication product of industrial grade.

The product is equipped with multiple application interfaces, including Ethernet interface, RS232 serial interface and RS485 serial interface, and thus can satisfy the user's various different application demands.

The product supports DIACloud platform services, and by this platform, convenient and efficient point-to-point connection with the router, safe and reliable data transmission, remote device management and configuration, remote firmware upgrading, remote maintenance and other functions can be realized, so as to save the cost of device operation and maintenance for users.


The product can be widely used in the fields requiring mobile network interconnection, such as industrial automation, smart home, intelligent building, smart power grids, video surveillance, intelligent self-service and intelligent transportation.



1.1.1 Network Design

Connect the intelligent devices at different sites to the Internet via the DX-2300LN-WW. The DX-2300LN-WW allows the point-to-point connection through DIACloud platform. In addition to safe and reliable data transmission, it can save the cost of purchasing and maintaining VPN device.


The maintenance personnel can realize remote maintenance and management of the device through DIACloud platform whenever and wherever possible, which can ensure safe and reliable data transmission, and also can save operation and management cost of the device for users.




1.1.2 Features

- Device support various connection method in WAN port, such as the static IP, DHCP client.
- Provide dual serial port (RS232 & RS485) and LAN port connectivity.
- Build in Watch-Dog.
- NTP server built in RTC.
- Local and remote firmware upgrade.
- Support Firewall: Stateful Packet Inspection (SPI), Prevent Denial of Service (DoS) Attacks, NAT (Network Address Translation), Port Triggering, Port Mapping, IP Address Filtering, MAC Address Filtering, URL Filtering, DHCP Server, Dynamic DNS, Static Routes, Demilitarized Zone (DMZ)
- TCP/IP, UDP, ICMP, DHCP, HTTP, DNS, SSH protocol
- Modbus TCP and Modbus RTU / ASCII protocol
- Mitsubishi MC and Siemens ISO TCP protocol
- SMS alarm functions, users can customize the alarm condition
- Provide task schedule management
- Local log and remote log server
- Configuration backup and importing
- Network data flow statistic
- Networking failure diagnostic
- DIACloud platform services that can realize safe point-to-point data transmission, remote device configuration and management, firmware upgrading, and support batch configuration and upgrading of multiple devices

1.1.3 Front Panel Ports and LEDs



1.1.4 Bottom Panel



Notice


This router's reset button is on the front panel. By pressing the Reset button, users can reset the router or reset the router to factory default settings. See the instruction below:

- Reset the Router: With the router powered on, press the Reset button and release the button right away.

- 1**
- **Reset to Factory Defaults:** With the router powered on, press and hold the Reset button for 3-6 seconds and then release the button.
 - Reset can only be done when the device is running properly.
 - With the router powered on, press and hold the Reset button until all the LEDs go out (Except the Power LED). Then release the button and wait the router to reboot to its factory default settings.

1.1.5 Dimension

Unit = mm



1.2 Package Checklist

Unpack the package carefully and check the package contents. The package should contain the following items:

- DX-2300LN-WW Industrial Ethernet Cloud Router x1
- Quick Installation Sheet x1
- Accessory for Wall-mounting installation x1



Notice

- Verify that nothing is missing from the DX-2300LN-WW package by using the check list above. If any item is found missing or damaged, please contact your local sales representative for support.

Chapter 2 User Interface

Table of Contents

2.1	Web-based GUI Configuration	2-2
2.1.1	System Connection	2-2
2.1.2	Default IP Address/Account/Password	2-2
2.1.3	Local Network Setups	2-2
2.1.4	Logging in.....	2-4
2.2	DIADevice	2-5
2.2.1	Device connection and detection	2-5
2.2.2	Network Setting.....	2-7
2.2.3	Bind Device.....	2-9
2.2.4	Open Device Webpage.....	2-11
2.3	Typical application configuration	2-5
2.3.1	Data Collection	2-12
2.3.2	Remote Debugging.....	2-18


2.1 Web-based GUI Configuration

The DX-2300LN-WW Industrial Ethernet Cloud Router provides a friendly Web Browser Configuration for users to set up and operate more intuitively.


2.1.1 System Connection

First, connect the PC used for configuration with Ethernet interface of the router directly or through the switch/hub.

Method I



Method II





2.1.2 Default IP Address/Account/Password

The default IP address of router is 192.168.5.5. The initial account and password is admin/admin.

2.1.3 Local Network Setups

After the connection of the local computer and the router is done, you will need to set the network configuration for your computer. There are 2 methods for the setting, we suggest you to use the first one:

- **Obtain an IP address automatically by using the router as a DHCP server.**
 1. Open Network Connections by clicking the Start button , and then clicking Control Panel.
 2. Under Network and Sharing Center, click View network connections.
 3. Right-click the connection that you want to change, and then click Properties.  If you're prompted for an administrator password or confirmation, type the password or provide confirmation.
 4. Click the Networking tab. Under This connection uses the following items, click either Internet Protocol Version 4 (TCP/IPv4) or Internet Protocol Version 6 (TCP/IPv6), and then click Properties.
 5. Click Obtain DNS server address automatically and then click OK to get a DNS server address automatically using DHCP.




- **Set up the IP address manually.**

(The IP address of the computer should be in the same network segment as the router's.)

Since the router's default IP address is 192.168.5.5 and the subnet mask is 255.255.255.0, the computer's IP address can be set between 192.168.5.1 to 192.168.5.254 except 192.168.5.5. However, you'll need to make sure there are no IP conflicts.


Here, we set the address to 192.168.5.10 and the default gateway to 192.168.5.5. For DNS, the usable DNS address can be selected or the address can also be set to 192.168.5.5.




2

2.1.4 Logging in


1. Open your Internet Explorer browser and input LAN IP address (Default is 192.168.5.5) in the search bar and then press Enter.



2. You'll be prompted with the log-in page. Input the user name and the password (Default is admin/admin) and then press Enter to log in to the setup page.



3. After login, you can see the main selection area on the left hand side and the upper area of the page. The detailed settings can be seen on the right hand side of the page.



2.2 DIADevice


DIADevice is a tool for quickly configuring network devices. Users simply connect the DX device to the PC through the network cable. This tool can be used to quickly and easily configure the network setting of the device and complete the device binding DIACloud cloud account.

The DIADevice software is included in the latest DIACom software package. From the official website or sales staff to obtain DIACom package. The following example uses DX-2300 to show you how to configure your device with DIADevice.


2.2.1 Device connection and detection

1. Connect the device to the power supply, and connect the device to the PC using a network cable. Plug the network cable connected to the Internet into the WAN port of the device
2. Run DIADevice and click 'Detect' button


2



3. After DIACom detects the device, it will automatically go to the login page, and the user needs to enter login password on the login page.



4. After passing the authentication, the device information page is displayed, including the basic device information (Device Name, S / N, firmware, LAN IP address), network status, WAN information, and cloud service information



The screenshot shows the DIA Device user interface. At the top, it says "DIA Device" with a close button. Below the title bar, there is a green checkmark and the text "Internet Connected". On the left, there is an image of a network device labeled "test" with a button "Open Device Webpage". On the right, there are two main configuration panels:

- WAN Panel:** Includes a "Network Setting" button. It shows:

WAN Type	DHCP
IP Address	[Redacted] 123
Gateway Address	[Redacted] 254
- Cloud Panel:** Includes a "Bind Device" button. It shows:


User Account	[Redacted] .com
Secure Tunnel	DeltaNetwork
Service Status	Enabled

At the bottom of the interface, the following information is displayed: Lan IP Address: 192.168.100.200, SN: DX23000216260055, and Firmware: DX2300WW-1.3.3.1-2016-11-17.

2.2.2 Network Setting

This feature allows you to quickly configure your network in three steps.

1. Click "Network Setting"



This screenshot is identical to the one above, showing the DIA Device user interface with the "Network Setting" button highlighted in the WAN panel.

- The default is DHCP. If you can not connect to the Internet using auto-setup, please use manual settings.

2

DIA Device

1

WAN Type: DHCP

IP Address: 172.16.155.123

Subnet Mask: 255.255.255.0

Gateway Address: 172.16.155.254

DNS: Dynamic

DNS Server: 172.16.144.200

Back Next

- Please confirm the network environment and then decide whether to enable HTTP Proxy. If you need to set up HTTP PROXY, contact your IT staff.

DIA Device

2

HTTP Proxy: Enabled

Proxy IP Address: []


Port: []

Username: []

Password: []

Prev Next


- After the device successfully connected to the Internet, the connection would be successful.



2.2.3 Bind Device

This feature allows you to quickly bind your device to the DIAcloud in three steps.

- Click "Bind Device"



2. Enter the DIAcloud account number and password, and click Next.

DIA Device

1

Cloud Account [redacted].com

Password [redacted]

* The operation will bind this device to new account.

Back Next

3. After binding configuration is configured, click "Bind" to bind.

DIA Device

1 2 3

Cloud Account [redacted].com

Device Name DX2100_B0B4

Secure Tunnel DeltaNetwork

Cloud DHCP Enabled


Retrieve IP address from cloud No

DHCP IP Range 192.168.100.100 - 192.168.100.200

LAN IP Address 192.168.100.100

Prev Bind

4. If your device is successfully bound to the cloud, the following screen will appear





Notice

- If the device has been bound to the cloud account, you need to switch to another cloud account binding, you only need to repeat 1-3 steps and then enter the new cloud account you need to bind

2.2.4 Open Device Webpage

Click "Open device webpage" button, the browser will open the device settings page, the user can set the parameters of RS232 / 485 configuration.

2




2.3 Typical application configuration

DX-2300 is an industrial-grade cloud router, with DX-2300 users can easily and quickly collect remote data and perform remote device debugging.

2.3.1 Data collection

DX router can connect to the Slave via serial port or Ethernet port, router builtin more than 2000 registers, through standard Modbus RTU ASCII and Modbus/TCP protocol, and Mitsubishi MC and Siemens TCP protocol, work as Master/Slave role to collect/receive data, and upload data to the cloud.

The basic steps of data collection are as follows:



1. Register DIACloud Account

Cloud account is an important credential of DX router ownership. When the router is bound with a DIACloud account, only the account or the sub-account authorized by the account can access the device remotely. All data uploaded by the router belongs to this account, which can only be accessed by this account or sub-accounts authorized by this account. If you don't already have a cloud account, follow these steps to register:

- Browsing DIACloud website (<http://www.DIACloudSolutions.com>), click "CREATE AN ACCOUNT".

DIACloud

Email *

Password *

Remember Me

LOGIN

[CREATE AN ACCOUNT](#) [FORGOT PASSWORD?](#)

Contact Us: web@diacLOUDSOLUTIONS.COM

- Fill in account info and select “I Agree”, click “CREATE AN ACCOUNT” button.

The screenshot shows a registration form with the following elements:

- Email *
- Password *
- Confirm Password *
- Radio buttons: Person, Enterprise
- Name *
- Country (dropdown menu)
- Verification Code * (with a refresh icon and the code A2G5U)
- I Agree (with a red **AGREEMENT** link)
- CREATE AN ACCOUNT button

- Login your mailbox. Open the activation email sent from no-reply@DIACloudSolutions.com and complete DIACloud account activation operation.

2. Config DX Router

Here shows how to config the DX router, make it as the modbus master to collect the data from Delta PLC via RS-485.

- Connect DX router to local PC via cable, login the config GUI, See section 2.1 for more details.
- DX-2300 is a wire router. You can go to “Network”-“WAN Configurations” to set up the parameters for internet connection.

🏠 NETWORK > WAN Configurations

☰ WAN Configurations

WAN Connection Mode	DHCP ▾
IP Allocation Method	Dynamic ▾
IP Address	0.0.0.0
Network Mask	0.0.0.0
Gateway Address	0.0.0.0
Packet MTU	1500
(Don't change the settings unless really need to)	
Retrieve DNS Address By:	Dynamic ▾
Primary DNS	0.0.0.0
Secondary DNS	0.0.0.0
Auto Detect	Cloud service ▾

Save

Cancel

After configuration, you can go to "Status"->"network status" to confirm the connection is ready.

☰ Internet Information

MAC Address	00:30:AB:35:8C:6C		
IP Address	██████████ ¹	Network Mask	255.255.255.0
Gateway Address	██████████ ¹	WAN Connection Mode	STATIC
Primary DNS	114.114.114.114	Secondary DNS	██████████ ²
WAN Status	Connected		

- Go to "System"->"RS485" and enter RS-485 setting page, set the working mode as "Master mode". Detail configuration is as follows::

2

☰ RS485

Working Mode ▾

Baud Rate ▾

Data Bits ▾

Stop Bits ▾

Parity Bits ▾

Slave ID

Mode ▾

Timeout (ms)

Read/Write Configuration

Scan Interval (ms)

When communicate with PLC of Delta, the starting address can be set as the internal register number. For example, input 0 for register D0.

The acceptable address range of this device is: \$0-\$1535 or \$2048-\$4095 or M0-M511.

Row Number	Read/Write	Slave ID	Controller	Address Type	Slave Starting Address	Bit	Device Starting Address	Length (1-123)	Operation
1	Read/Write ▾	1	Delta DVP PLC ▾	D ▾	100	0	\$2048	10	<input type="button" value="+"/> <input type="button" value="-"/>

- Go to "System"-“Register Management” and enter register setting page, set up the data upload rules. Detail configuration is as follows:

☰ Add

Register Type ▾

Register Address (\$2048-4095, M0-511)

Length

Uploaded To Cloud ▾

Keep History ▾

- Go to "Cloud Service"-“Cloud configurations”and enter account setting page, binding the device with DIACloud account. Detail configuration is as follows:

🏠 CLOUD SERVICE > Cloud Configurations

☰ Cloud Configurations

User Name:

Password:

Parts of firewall function will loss effect when device is binding success!

Click the "verify" button to verify the user name/password, it will show below page after verification is pass. Users can use the default parameters. Click the "bind" button to bind the device to this account.

☰ Cloud Configurations

User Name:

Password:

Parts of firewall function will loss effect when device is binding success!

Secure Tunnel:

Device Name:

Secure Tunnel DHCP: Not available

When DHCP server in the secure tunnel network is not available, the IP address of the secure tunnel will be the LAN IP, if you want to change it ,please go to LAN configuration web page

Device IP:

Network Protocol:

After binding successful, you can log in the device configuration page again and check the binding information.

🏠 CLOUD SERVICE > Cloud Configurations

User Name:	diacloud@163.com	
Registration Status:	Registered	<input type="button" value="Unbind"/>
Service Status:	Enabled	<input type="button" value="Disable"/>
Secure Tunnel:	default	
Device Name:	DX2300_8C8B	
Secure Tunnel DHCP:	Not available	
Device IP:	192.168.10.40	
Network Protocol:	UDP	

3. View data in DIACloud

- Browsing DIACloud website, login with your account.
- Click “Devices” from the menu, find the device and click the ******* to view the details.
- Select “Registers” and a register list will be displayed, values shown behind register addresses are collected data.

OVERVIEW	REGISTERS	SERVICES	MORE
<input type="text" value="Search"/> < 1/200 >			
\$2048	22363  2018-07-27 03:04		
\$2049	22232  2018-07-27 03:04		
\$2050	22206  2018-07-27 03:04		
\$2051	0  2018-06-06 17:56		
\$2052	0  2018-06-06 17:56		
\$2053	22214  2018-07-27 03:04		
\$2054	10  2018-06-06 17:56		
\$2055	22047  2018-07-27 03:04		
\$2056	3  2018-06-06 17:56		

2.3.2 Remote debugging

DX router have built-in DIACloud cloud service, so when the router is bound to the DIACloud account and connected to the DIACloud cloud platform, the router and the cloud platform will create a secure tunnel, and all the devices in the same secure tunnel group under the account will be in the same secure virtual LAN. With our DIACom PC tool, users can also add their local computers to the virtual LAN, allowing them to download and debug remote devices as if they were operating locally, either through the network port or by creating a virtual serial port.

Register DIACloud Account

Config DX Router

- Network setting
- Interface setting
- Cloud account setting

DIACom Tool

- Installion and Login
- Create secure tunnel
- Remote debug

1. Register DIACloud Account

If you've already had a DIACloud account, skip this step. To register a new account, please refer to section 2.3.1.

2. Config DX Router

Here show how to config the DX router and perform remote debug Delta PLC via RS-485.

- Connect DX router to local PC via cable, login the config GUI, See section 2.1 for details

DX-2300 is a wire router. You can go to "Network"->"WAN Configurations" to set up the parameter for internet connection. After configuration, you can go to "Status"->"network status" to confirm the connection is ready.

Internet Information

MAC Address	00:30:AB:35:8C:6C		
IP Address	██████████ ¹	Network Mask	255.255.255.0
Gateway Address	██████████ ⁴	WAN Connection Mode	STATIC
Primary DNS	114.114.114.114	Secondary DNS	██████████ ²
WAN Status	Connected		

- Go to "System"->"RS485" to enter RS-485 setting page, set up it's working mode to "Transparent mode", configuring as follows:

🏠 SYSTEM > RS485

☰ RS485

Working Mode	Transparent mode ▾
Baud Rate	9600 ▾
Data Bits	8 ▾
Stop Bits	1 ▾
Parity Bits	None ▾

Save

Cancel

- Go to “Cloud Service”-“Cloud configurations” to enter account setting page, binding the device with DIACloud account, please refer to section 2.3.1 for more details.

3. DIACom Tool

- Obtain the DIACom firmware package from the official website or from our sales representative. Administrator privileges are required to run and install the package. After install successfully, run this programe and login with DIACloud account.



- Select the tunnel group which router belongs to. Set up local IP address same segment with DX route. And click “Create Tunnel” button.



DIACom Secure Tunnel

Local IP address DHCP Static Cloud DHCP disabled Create Tunnel

192 - 168 - 10 - 2 / 255 - 255 - 255 - 0

Status	Name	SN	Latency	IP Address	Operation
Online	DX2300_8C8B	DX23000316180001	22 ms	192.168.10.40	
Offline	VR500L1_7AE6	VR05000218410024	-	192.168.5.5	
Offline	告警测试	DX21000218420008	-	192.168.200.10	
Offline	VR500L1_6D81	VR05000218290012	-	192.168.5.5	
Offline	DX501L1_7B09	DX05010118410059	-	10.181.150.33	
Offline	lilytest	VR05000217220010	-	10.128.157.158	
Offline	VR500L1_2323	VR05000218010101	-	10.103.138.86	
Offline	VR500L1办公室挂机(勿动)	VR05000218290039	-	10.56.71.135	
Offline	VR-500H1	VR05000218201234	-	10.112.239.213	
Offline	VR-500H1	DX05000218290030	-	10.108.69.82	
Offline	VR-500H1	VR05000218290101	-	10.59.127.219	

Local IP Address N/A



DIACom Secure Tunnel

Local IP address DHCP Static Cloud DHCP disabled Disconnect



192 - 168 - 10 - 2 / 255 - 255 - 255 - 0

Status	Name	SN	Latency	IP Address	Operation
Online	DX2300_8C8B	DX23000316180001	21 ms	192.168.10.40	
Offline	VR500L1_7AE6	VR05000218410024	-	192.168.5.5	
Offline	告警测试	DX21000218420008	-	192.168.200.10	
Offline	VR500L1_6D81	VR05000218290012	-	192.168.5.5	
Offline	DX501L1_7B09	DX05010118410059	-	10.181.150.33	
Offline	lilytest	VR05000217220010	-	10.128.157.158	
Offline	VR500L1_2323	VR05000218010101	-	10.103.138.86	
Offline	VR500L1办公室挂机(勿动)	VR05000218290039	-	10.56.71.135	
Offline	VR-500H1	VR05000218201234	-	10.112.239.213	
Offline	VR-500H1	DX05000218290030	-	10.108.69.82	
Offline	VR-500H1	VR05000218290101	-	10.59.127.219	

Secure tunnel is set up. 52 ms Local IP Address 192.168.10.2

- After the tunnel has been created, click  button of the DX router, goto create virtual com page. If "Create" button is not available, please check the RS-485 wrok mode in DX router config page.

2



- After the virtual serial port is created, open the corresponding debugging tool WPLSoft of Delta PLC, you can remotely download the program to the PLC, which connect to DX router through RS-485.

Communication Setting

Connection Setup
Type: RS232

Communication Setting
COM Port: COM5 ... ASCII
Data Length: 8 RTU (8 bits)
Parity: Even
Stop Bits: 1 Auto-detect
Baud Rate: 9600
Station Address: 1 Default

Ethernet Setting
 Assign IP: 192.168. 1. 5
Port: 502

Baud Rate Decided by
 PLC Setting
 WPL Setting

Setup Responding Time
Times of Auto-retry: 3
Time Interval of Auto-retry (sec.): 3

OK Cancel

MEMO

2

Chapter 3 Functions

Table of Contents

3.1	Status	3-3
3.1.1	Device Information	3-3
3.1.2	Network Status	3-4
3.1.3	Routing Table.....	3-5
3.1.4	Local Log.....	3-5
3.1.5	Traffic Statistics	3-6
3.1.6	Cloud Status.....	3-6
3.1.7	Connected Device.....	3-6
3.2	Network	3-7
3.2.1	WAN Configurations	3-7
3.2.2	LAN Configurations	3-9
3.2.3	Storm Filtering	3-11
3.2.4	Static Routing Rules.....	3-11
3.2.5	Dynamic DNS.....	3-13
3.3	Firewall	3-14
3.3.1	Firewall Settings.....	3-14
3.3.2	DMZ Settings	3-17
3.3.3	Port Forward.....	3-17
3.3.4	Port Trigger	3-20
3.3.5	URL Filter	3-21
3.3.6	MAC Filter	3-22
3.3.7	IP Filter	3-23
3.4	System	3-24
3.4.1	User Management.....	3-24
3.4.2	Time Zone Configurations	3-25
3.4.3	RS232	3-26
3.4.4	RS485	3-36
3.4.5	Modbus TCP.....	3-44
3.4.6	Siemens TCP.....	3-47
3.4.7	Log Settings	3-50
3.4.8	Firmware Upgrade	3-51

3.4.9	Backup & Restore	3-52
3.4.10	Scheduled Jobs	3-53
3.4.11	Add A New Job.....	3-53
3.4.12	Export Job List	3-54
3.4.13	Import Job List.....	3-54
3.4.14	Network Diagnosis.....	3-54
3.4.15	Trouble shooting	3-55
3.4.16	System Reboot	3-56
3.4.17	Event Management.....	3-56
3.4.18	Register Management	3-59
3.5	Cloud Service	3-60
3.5.1	Cloud Configurations.....	3-60
3.5.2	Proxy Setting.....	3-65
3.5.3	Secure Tunnel Firewall	3-66
3.5.4	Cloud Log.....	3-67
3.6	SD Card Quick Configuration	3-68

3.1 Status

You can view summary or detailed information on the Device Information, Network Status, Routing Table, Local Log, Traffic Statistics, Cloud Status, and Connected Device.

3.1.1 Device Information

This page shows basic information on the Hardware/Software version and Resource Usage Information.

[STATUS](#) > Device Information

Hardware Version

RTM Version: BlueGinger-DX2300 v1
 Release Date: 2015-02-15 05:05:37 AM
 S/N: DXL02040D340005

Software Version

RTM Version: BlueGinger-DX2300 0.5.0
 Release Date: 2015-02-15 05:05:37 AM
 Current Version: DX2300WW-1.3.1.1-2016-04-29
 Upgrade Date: 2016-04-29 17:24:07

Resource Usage Information

CPU Usage: 15%
 Total Memory: 123832KB
 Memory Used: 62124KB
 Memory Usage: 50%

- Hardware Version

Item	Description
RTM Version	Release to manufacturing version of the router
Release Date	Hardware release date
S/N	Serial number of the router

- Software Version

Item	Description
RTM Version	Release to manufacturing version of the software

Release Date	Software release date
Current Version	Version number of the software currently used on the router
Upgrade Date	Upgrade time of the software currently used on the router

- Resource Usage Information

Item	Description
CPU Usage	The CPU usage of current router
Total Memory	The total memory on the router
Memory Used	The memory currently used on the router.
Memory Usage	The current ratio of the router usage

3.1.2 Network Status

This page shows basic information on Internet Information and LAN Status.

Internet Information includes the MAC Address, IP Address, Gateway Address, Primary DNS, Network Mask, WAN Connection Mode, and Secondary DNS.

LAN Status includes the Device Name, IP Address, DHCP Server, MAC Address and Network Mask. When the DHCP server is enabled, you can see more information, including the address lease time, start address and end address.

[🏠 STATUS > Network Status](#)

☰ Internet Information

MAC Address	00:23:11:22:33:4C		
IP Address	0.0.0.0	Network Mask	0.0.0.0
Gateway Address	0.0.0.0	WAN Connection Mode	DHCP
Primary DNS	0.0.0.0	Secondary DNS	0.0.0.0

☰ LAN Status

Device Name	DX2300_334D	MAC Address	00:23:11:22:33:4D
IP Address	192.168.1.1	Network Mask	255.255.255.0
DHCP Server	Enabled		
Lease Time	One day		
First IP Address	192.168.1.100	Last IP Address	192.168.1.200

3.1.3 Routing Table

This page shows basic information on the routing table, including the Destination, Gateway, Network Mask, HOPS and Network Interface.

[STATUS](#) > Routing Table

Destination	Gateway	Network Mask	HOPS	Network Interface
192.168.1.0	0.0.0.0	255.255.255.0	0	br0

3.1.4 Local Log

This page shows logs of the router, including the System log, Warning log and the Debug log. You can use the buttons on the right hand side to refresh, clear or download the displayed logs.

[STATUS](#) > Local Log

Log Type

Informative log
 Warning log
 Debug log

Log Content

Refresh

Clear

Download

Timestamp	Content
May 12 13:42:47	syslog.info syslogd started: BusyBox v1.15.0
May 12 13:42:51	user.info kernel: ip_tables: (C) 2000-2006 Netfilter Core Team
May 12 13:42:53	user.info kernel: ipt_CLUSTERIP: ClusterIP Version 0.8 loaded successfully
May 12 13:42:54	user.info kernel: arp_tables: (C) 2002 David S. Miller
May 12 13:42:57	user.info kernel: usbcore: registered new interface driver usbserial
May 12 13:42:57	user.info kernel: USB Serial support registered for generic
May 12 13:42:57	user.info kernel: usbcore: registered new interface driver usbserial_generic
May 12 13:42:57	user.info kernel: usbserial: USB Serial Driver core
May 12 13:42:58	user.info kernel: USB Serial support registered for GSM modem (1-port)
May 12 13:42:58	user.info kernel: usbcore: registered new interface driver option
May 12 13:42:58	user.info kernel: option: v0.7.2:USB Driver for GSM modems
May 12 13:42:58	user.info kernel: USB Serial support registered for Vizzini USB serial port

PREV

1

2

3

...

5

6

7

NEXT

3.1.5 Traffic Statistics

This page shows network traffic information of the router, including the data sent and received over WAN and LAN. You can use the buttons on the right hand side to refresh or clear the traffic information.

[STATUS](#) > Traffic Statistics

Refresh

Clear

Traffic Of WAN

Data Sent: 590 bytes Data Received: 0 bytes

Traffic Of LAN

Data Sent: 621874 bytes Data Received: 471204 bytes

3.1.6 Cloud Status

This page shows cloud server information of the router, including the Registration Status, Service Status, and Activated Time.

[STATUS](#) > Cloud Status

Cloud Status

Registration Status: Not registered

Service Status: Disabled

Activated Time: N/A

3.1.7 Connected Device

This page shows information of the devices connected to the router, including the IP Address, Host Name, MAC Address.

[STATUS](#) > Connected Device

Refresh

ID	IP Address	Host Name	MAC Address
1	192.168.1.100	CNXMDNIPC062	3C:97:0E:DE:7B:25

3.2 Network

You can set up networks, including the WAN Configurations, LAN Configurations, Storm Filtering, Static Routing Rules and Dynamic DNS.

3.2.1 WAN Configurations

This page is used for setting up the WAN (Wide Area Network), including the WAN Connection Mode, IP Allocation Method, IP Address, Network Mask, Gateway Address, Packet MTU and DNS.

[🏠 NETWORK](#) > WAN Configurations

☰ WAN Configurations

WAN Connection Mode	<input type="text" value="DHCP"/>
IP Allocation Method	<input type="text" value="Dynamic"/>
IP Address	<input type="text" value="0.0.0.0"/>
Network Mask	<input type="text" value="0.0.0.0"/>
Gateway Address	<input type="text" value="0.0.0.0"/>
Packet MTU	<input type="text" value="1500"/>
(Don't change the settings unless really need to)	
Retrieve DNS Address By:	<input type="text" value="Dynamic"/>
Primary DNS	<input type="text" value="0.0.0.0"/>
Secondary DNS	<input type="text" value="0.0.0.0"/>
Auto Detect	<input type="text" value="Cloud service"/>

Description	Default
WAN Connection Mode	
Your device can connect to the internet via the WAN port with a Dynamic IP or Static IP. <ul style="list-style-type: none"> Static IP: Manually set up the IP address. Dynamic IP: DHCP (Dynamic Host Configuration Protocol) server on the network will assign an IP address to the DX router automatically. 	DHCP
IP Allocation Method	
The IP Allocation Method is the same as the WAN Connection Mode that	DHCP

Description	Default
<p>you have set. You can apply to different option by modifying the WAN Connection Mode.</p> <ul style="list-style-type: none"> Dynamic: DHCP (Dynamic Host Configuration Protocol) server on the network will assign an IP address to the DX router automatically. Manual: Manually set up the IP address (Static). 	
IP Address	
Set up an IP address for your device to connect to the internet via the WAN port. It's configurable when the mode is set to Static.	0.0.0.0
Network Mask	
Set up the WAN network mask. It's configurable when the mode is set to Static.	0.0.0.0
Gateway Address	
Set up the gateway address. It's configurable when the mode is set to Static.	0.0.0.0
MTU	
Maximum Transmission Unit is the largest packet that can be transmitted over packet based networks.	1500
Retrieve DNS Address By	
<p>The Retrieve DNS Address Method is the same as the WAN Connection Mode that you have set. You can apply to different option by modifying the WAN Connection Mode.</p> <p>DNS address can be retrieved by DHCP setup or manually set.</p> <ul style="list-style-type: none"> Dynamic: DHCP (Dynamic Host Configuration Protocol) server on the network will assign an DNS address to the DX router automatically. Manual: Manually set up the IP address (Static). 	DHCP
Primary DNS	
Set up the primary DNS. It's configurable when the mode is set to Static.	0.0.0.0
Secondary DNS	
Set up the secondary DNS. It's configurable when the mode is set to Static.	0.0.0.0
Auto Detect	
With two ways to detect the network connection automatically, users can choose between "PING" and "Cloud Service" or choose "Disable" to shut down this function.	Cloud Service
Target Address	
Set the IP/domain of the server that program will do a ping testing.	www.DIACloudSolutions.com

3.2.2 LAN Configurations

This page is used for setting up the LAN, including the Device Name, IP Address, Network Mask, and DHCP Server.

[🏠 NETWORK > LAN Configurations](#)

☰ LAN Configurations

Device Name	<input type="text" value="DX2300_8C8B"/>
IP Address	<input type="text" value="192.168.5.5"/>
Network Mask	<input type="text" value="255.255.255.0"/>
DHCP Server	<input type="text" value="Enable"/>
Address Lease Time	<input type="text" value="One day"/>
First IP Address	192.168.5. <input type="text" value="100"/>
Last IP Address	192.168.5. <input type="text" value="200"/>
STP	<input type="text" value="Disable"/>
PHY Auto Reset	<input type="text" value="Disable"/>

Description	Default
Device Name	
Set up a device name for your router. The name shall be composed of letters, numbers and underline, starting with a letter or number. The maximum string length is 32 bytes.	DX2300 + “_” + “the last four digits of Mac address”
IP Address	
Set up an IP address for your device.	192.168.5.5
Network Mask	
Set up the LAN network mask.	255.255.255.0
DHCP Server	
If DX router uses DHCP to assign IP addresses automatically on your network. You can specify the IP address range and lease time for the clients on your network. Once the DX router have bound the DIACloud and enabled the DIACloud DHCP the DHCP in DX router will be disabled automatically.	Enable
Address Lease Time	
To set up the address lease time so that a client doesn't hold an IP address indefinitely. It allows for a mechanism to gracefully reuse DHCP addresses.	One day

Description	Default
Options here are 1 to 3 days.	
First IP Address	
To increase the number of addresses available to clients, you can change the Start Address.	192.168.5.100
Last IP Address	
To increase the number of addresses available to clients, you can change the End Address.	192.168.5.200
STP	
STP is a network protocol that builds a logical loop-free topology for Ethernet networks. The basic function of STP is to prevent bridge loops and the broadcast radiation that results from them. If this STP is enabled, the traffic usage will increase about 15Mbit in 24 hours.	Disable
PHY Auto Reset	
<p>Activate DIACloud DHCP after the account is bound. To determine whether LAN needs to be reset if DIACloud is manually reboot or reconnected due to unstable network.</p> <ul style="list-style-type: none"> ● Disable: Not allow LAN reset automatically. ● Enable: Allow LAN to be reset which would cause a short period of disconnection between devices and DX LAN ports <p> Notice:</p> <p>It is suggested to disable DIACloud DHCP function and assign IP addresses in manual mode.</p>	Disable

An example of operation: Confirm “PHY Auto Reset” is set as Disable.

Instruction	<ol style="list-style-type: none"> 1. Logged into www.diacloudsolutions.com 2. Click the secure tunnel and create a new network. 3. Enable the function to assign IP address 4. Log into DX webpage and bind your account to the DIACloud. Make sure if the LAN port is receiving the DHCP IP address from DIACloud. 5. Go to NETWORK -> LAN Configurations -> PHY Auto Reset and select Disable. 6. Connect the device to the LAN1 port. 7. Restart the Cloud service to see if the LAN1 is not trying to reconnect. (LAN1 should not be restarted.) 8. Connect your PC to LAN2 to ping LAN1 to see if the IP address of the LAN1 cannot communicate for a short time.
-------------	--

3.2.3 Storm Filtering

When storm filtering is enabled, the switch will permit only the allowed number of packets to forward during the period you set, and the following incoming packets will be discarded to avoid network traffic.

🏠 NETWORK > Storm Filtering

When storm filtering is enabled, the switch will permit only the allowed packet numbers packets you setted to forward to other ports during the period,and the following incoming packets will be dropped !

Broadcast Packet Filtering	Disabled ▾
Multicast Packet Filtering	Disabled ▾
Unknown Destination Address Packet Filtering	Disabled ▾
Period	800ms ▾
Allowed Packet Number	8 ▾

Save

Cancel

Description	Default
Broadcast Packet Filtering	
Enable or disable storm filtering function for broadcast packets. Condition to determine: Destination: FF:FF:FF:FF:FF:FF, protocols: DHCP \ ARP \ UDP...	Disabled
Multicast Packet Filtering	
Enable or disable storm filtering function for Multicast packets. Condition to determine: Destination: multicast MAC addresses 01-80-C2-XX-XX-XX, 01-00-5E-XX-XX-XX and more. Protocols: IGMP... Note: Conditions not include 01-80-C2-00-00-00(STP protocol)	Disabled
Unknown Destination Address Packet Filtering	
Enable or disable storm filtering function for unknown destination address packets.	Disabled
Period	
Set the time period of storm filtering with options: 800ms, 400ms, 200ms and 100ms.	800ms
Allowed Packet Number	
Set the allowed packet number to process in a time period. Options are 8, 16, 32, 64 and 256.	8

3.2.4 Static Routing Rules

This page is for setting up the Static Routing, including the Rule Name, Network Interface, Enabled, Destination IP, Network Mask, Gateway Address and Metric. Click the "Add A Rule" to add static routing rules.

Add A Rule

ID	Enabled	Name	Destination	Gateway	Network Interface
----	---------	------	-------------	---------	-------------------

After clicking the "Add A Rule" , you will see the following page.

☰ Add A Rule

3

Rule Name

Network Interface

Enabled

Destination IP

Network Mask

Gateway Address

Metric (2~15)

Save Back

Description	Default
Rule Name	
Set up a name for your rule. The name shall be composed of letters, numbers and underline, starting with a letter or number. The maximum string length is 32 bytes.	N/A
Network Interface	
For a specific network destination address, select the network interface of the router for sending data package. Options are LAN and WAN.	WAN
Enabled	
Activate the static routing functionality.	Yes
Destination IP	
Set up a Destination IP address for your device.	N/A
Network Mask	
Set up the subnet mask corresponding to the destination network segment. If the final destination of the routing is a single host, please type in 255.255.255.255.	N/A
Gateway Address	
Set up the next-hop routing address.	N/A

Description	Default
Metric	
Set up the hops. The number of hops that are passed for reaching the destination address. One hop indicates passing one router passed. The range is 2~15.	2

3.2.5 Dynamic DNS

This page is used for setting up the Dynamic DNS Settings, including the Dynamic DNS, Service Provider, Domain User Name, Password, and the Refreshing Interval.

🏠 NETWORK > Dynamic DNS

Dynamic DNS Settings

Dynamic DNS	Disable ▾
Service Provider	www.DynDns.org ▾
Domain	<input type="text"/>
User Name	<input type="text"/>
Password	<input type="password"/>
Refreshing Interval	86400 (120~86400s)

Description	Default
Dynamic DNS	
Dynamic Host Configuration Protocol allows you to obtain an IP address automatically from your router. You can enable or disable this functionality.	Disable
Service Provider	
Select the dynamic domain service provider. Options are www.DynDNS.org and www.NOIP.com	www.DynDns.org
Domain	
The domain applied for to the corresponding dynamic domain service provider.	N/A
User Name	
The name of the user registered at the corresponding dynamic domain service provider.	N/A

Description	Default
Password	
The corresponding password to the registered user.	N/A
Refreshing Interval	
Set up the time for the router to update its public network IP from the dynamic domain service provider. The value range is 120~86400 sec.	86400

3.3 Firewall

You can set up firewall configurations, including the Firewall Settings, DMZ Settings, Port Forward, Port Trigger, URL Filter, MAC Filter, and IP Filter.

3.3.1 Firewall Settings

1. This page is used for setting up the basic firewall settings, including the SPI firewall switch, WAN Ping response, LAN SSH function and WAN SSH.
2. Users can also set up configuration via web browser by accessing the public IP address obtained from WAN port with port 80 or 502.

Use the MODBUS TCP Client tool and
Server IP will be 123.123.123.1:502



Public IP address
123.123.123.1:502



Access with
<http://123.123.123.1:80> via Web
browser to setup DX configuration



Public IP address
123.123.123.1:80



🏠 FIREWALL > Firewall Settings

☰ Basic Firewall Settings

Firewall	Enable ▾
WAN Ping	Not responded ▾
LAN SSH	Enable ▾
WAN SSH	Disable ▾
Remote Access Port	<input type="checkbox"/> 80 <input type="checkbox"/> 502

Save

Cancel

Description	Default
Firewall	
The SPI Firewall keeps track of the state of network connections travelling across it, protecting your Internet connection against Internet threats and Denial of Service (DoS).	Enable
WAN Ping	
It creates a filter that your router not to respond to Ping command and prevents other users on the internet from pinging your pc and gaining your IP address.	Not responded
LAN SSH	
Set up whether to allow LAN end to connect with the router via SSH.	Enable
WAN SSH	
Set up whether to allow WAN end to connect with the router via SSH.	Disable
Remote Access Port	
<p>Users can obtain a public IP address through the WAN port and use the port 80 to go to the setting page of the device and use the port 502 to connect to the Modbus TCP Server.</p> <ul style="list-style-type: none"> ● Port 80: Access the configuration page of your device. ● Port 502: External devices as MODBUS Clients connect to the MODBUS TCP Server of your device to read MODBUS slave devices. <p> Notice: Contact ISP or IT specialists in your company before obtain public IP address.</p>	Uncheck

1. **Access the DX configuration page with public IP address and port 80 on a remote computer.**

Access with
<http://123.123.123.1:80> via Web
 browser to setup DX configuration



Public IP address
 123.123.123.1:80



2. Login DX webpage.
3. Go to NETWORK -> Connection
4. Set "Primary Connection" as WAN
5. Obtain the public IP address from ISP (E.g.123.123.123.1)
6. Go to FIREWALL -> Firewall Settings
7. Check the box of Remote Access Port: 80.
8. Open the web browser on a remote PC and access the IP address (<http://123.123.123.1:80>) to enter DX configuration webpage.
9. **Use MODBUS TCP Client tool to connect with MODBUS TCP Server on DX devices and obtain MODBUS data**

Use the MODBUS TCP Client tool and
 Server IP will be 123.123.123.1:502



Public IP address
 123.123.123.1:502



10. Login DX webpage.
11. Go to NETWORK -> Connection
12. Set "Primary Connection" as WAN
13. Obtain the public IP address from ISP (E.g.123.123.123.1)
14. Go to FIREWALL -> Firewall Settings
15. Select "502" for Remote Access Port.
16. Remote devices use MODBUS TCP Client tool to connect with MODBUS TCP Server on DX devices and read MODBUS slave devices.

Example

Figure

🏠 FIREWALL > Firewall Settings

☰ Basic Firewall Settings

Firewall

WAN Ping

LAN SSH

WAN SSH

Remote Access Port 80 502

3

3.3.2 DMZ Settings

This page is used for setting up the DMZ server.

🏠 FIREWALL > DMZ Settings

☰ DMZ Settings

DMZ Server

DMZ Host IP Address

Description	Default
DMZ Server	
Demilitarized zone (DMZ) is a special segment of the local network reserved for servers accessible from the Internet, adding an additional layer of security.	Disable
DMZ Host IP Address	
Set up the IP address for the DMZ host.	N/A

3.3.3 Port Forward

This page is used for setting up the port forward, including configuring the Network Services, Service Name, Protocol, Public Port, Server Port, and Server IP Address.

1. Click the "Add A Portforward Rule" to add port forwarding entries to the router.

🏠 FIREWALL > Port Forward

Add A Portforward Rule

ID	Service Name	Protocol	Public Port	Server Port	Server IP Address
----	--------------	----------	-------------	-------------	-------------------

2. After clicking the "Add A Portforward Rule", you will see the following page.

🏠 FIREWALL > Port Forward

☰ Add A Portforward Rule

Network Services

Service Name

Protocol

Public Port (1~65534)

Server Port (1~65534)

Server IP Address 192.168.1.

3

Description	Default
Network Services	
Select the common network services. Refer to the following common service list for optional values.	Customized
Service Name	
Set up the service name for port forwarding. The name is composed of letters, numbers and underline, starting with a letter or number. The maximum string length is 32 bytes.	N/A
Protocol	
Set up the protocol type for port forwarding.	TCP/UDP
Public Port	
Set up the public port for port forwarding. The port range is 1~65534. A Public port should be less than or equal to the server port.	Single Port
Server Port	
Set up the server port for port forwarding. The port range is 1~65534. A server port should be greater than or equal to the public port. When the public port is set to a Single Port, the server port can only be set to a Single Port. When the public port is set to a Port Range, the server port can be set to a Single Port or a Port Range. And when the public port is set to a single port, all the port will be forwarded to ONE single port. Examples of different port forwarding settings:	Single Port

Description		Default
1:1		
Public Port	Single port ▼ 1001 (1~65534)	
Server Port	Single port ▼ 80 (1~65534)	
N:1		
Public Port	A port range ▼ 1001 - 1008 (1~65534)	
Server Port	Single port ▼ 80 (1~65534)	
N:N		
Public Port	A port range ▼ 1001 - 1008 (1~65534)	
Server Port	A port range ▼ 1001 - 1008 (1~65534)	
Server IP Address		
Set up the server IP address that applies to the port mapping rule.		192.168.1.*

Common Service List for Port Forwarding			
Service name	Protocol	Starting Port	Ending Port
Customized	TCP, UDP, TCP/UDP	1~65534	1~65534
FTP	TCP	20	21
HTTP	TCP	80	80
ICUII	TCP	23566	23566
IP_PHONE	TCP	6670	6670
NetMeeting	TCP	1720	1720
News	TCP	119	119
PPTP	TCP/UDP	1723	1723
Telnet	TCP	23	23
Quakel/III	TCP/UDP	27960	27960
Real-Audio	TCP	6970	7170

3.3.4 Port Trigger

This page is used for setting up the port trigger, including configuring the Service Name, Service User, Service Type, Trigger Port, Protocol Role, Begin Port, End Port, and Status.

Port triggering is port forwarding with an on/off switch for the ports that have been forwarded. Have data flow out of a trigger port or not by enabling or disabling this functionality. Set up the time for the Port Trigger Timeout and click "Save" to save the setting.

1. Click the "Add A Trigger Rule" to add port trigger entries to the router.

[FIREWALL](#) > [Port Trigger](#)

Port Trigger Port Trigger Timeout Minute

ID	Service Name	Service Type	Inbound Connection	Service User	Status
----	--------------	--------------	--------------------	--------------	--------

2. After clicking the "Add A Trigger Rule", you will see the following page.

[FIREWALL](#) > [Port Trigger](#)

Add A Trigger Rule

Service Name

Service User

Service Type

Trigger Port (1~65534)

Inbound Connection

Protocol Role

Begin Port (1~65534)

End Port (1~65534)

Status

Description	Default
Service Name	
Set up the service name for port triggering. The name is composed of letters, numbers and underline, starting with a letter or number. The maximum string length is 32 bytes.	N/A
Service User	
Select the service user to apply the port triggering rule.	Any Address

Description	Default
Service Type	
Set up the protocol type for port triggering.	TCP
Triggering Port	
Set up the triggering port. The port range is 1~65534.	N/A
Inbound Connection	
Protocol Role	
Set up the protocol type for the inbound connection.	TCP/UDP
Begin port	
Set up the starting port for the inbound connection. The port range is 1~65534.	N/A
End Port	
Set up the ending port for the inbound connection. The port range is 1~65534.	N/A
Status	
Enable/disable the port triggering functionality.	Disabled

3.3.5 URL Filter

This page is used for setting up the URL Filter, including configuring the URL Address, LAN IP Address and Status.

URL Filter is used to block particular website from the local network. Select Enable/Disable to activate/deactivate this functionality. Click the "Add An URL Address" to block the URL.

[HOME](#) [FIREWALL](#) > [URL Filter](#)

URL Address Filter

ID	URL Address	LAN IP Address	Status
----	-------------	----------------	--------

After clicking the "Add An URL Address" , you will see the following page.

[HOME](#) [FIREWALL](#) > [URL Filter](#)

Add URL

URL Address

LAN IP Address

Status

Description	Default
URL Address	
Manually input the URL address that you'd like to block, for example www.baidu.com.	N/A
LAN IP Address	
Set up the LAN IP address that you'd like to block. Options are "Any Address", "Single Address" and "Address Range".	Any Address
Status	
Enable/disable the URL Filter functionality.	Enabled

3.3.6 MAC Filter

This page is used for setting up the MAC Filter, including configuring the MAC Address, Device Name and Status.

MAC Filter is used to block particular MAC address from the local network. Select Enable/Disable to activate/deactivate this functionality. Click the "Add A MAC Address" to block the MAC Address.

[FIREWALL](#) > [MAC Address Filter](#)

MAC Address Filter

ID	MAC Address	Device Name	Status
----	-------------	-------------	--------

After clicking the "Add A MAC Address" , you will see the following page.

[FIREWALL](#) > [MAC Address Filter](#)

Add A MAC Address

MAC Address

Device Name

Status

Description	Default
MAC Address	
Manually input the MAC address that you'd like to block.	N/A
Device Name	
Set up the device name corresponding to the set MAC address.	N/A
Status	
Enable/disable the MAC Filter functionality.	Enabled

3.3.7 IP Filter

This page is used for setting up the IP Filter, including configuring the Source IP, Source Port, Destination IP, Destination Port, Protocol and Status.

IP Filter is used to block particular IP address from the local network. Select Enable/Disable to activate/deactivate this functionality. Click the "Add An IP Address" to block the IP Address.

[🏠 FIREWALL > IP Address Filter](#)

IP Address Filter Disable ▾ Save Add An IP Address

ID	Source IP Address Range	Source Port Range	Range Of Destination IP Address	Range Of Destination Port	Protocol	Status
----	-------------------------	-------------------	---------------------------------	---------------------------	----------	--------

After clicking the "Add An IP Address" , you will see the following page.

[🏠 FIREWALL > IP Address Filter](#)

☰ Add An IP Address

Source IP Any address ▾

Source Port Any port ▾

Destination IP Any address ▾

Destination Port Any port ▾

Protocol TCP/UDP ▾

Status Enabled ▾

Save Back

Description	Default
Source IP	
Set up the source IP.	Any Address
Source Port	
Set up the source port where the datagram came from.	Any port
Destination IP	
Set up the destination IP.	Any Address
Destination Port	
Set up the destination port where the datagram is going to.	Any port
Protocol	
Set up the protocol type for the IP Filter.	TCP/UDP
Status	
Enable/disable the URL Filter functionality.	Enabled

3.4 System

You can set up the system configurations, including the User Management, Time Zone Configurations, RS232, RS485, Modbus TCP, Log Settings, Firmware Upgrade, Backup & Restore, Scheduled Jobs, Network Diagnosis, System Reboot, Event Management, and Register Management.

3.4.1 User Management

You can change the administrator password here. The password must be a combination of 5 to 12 characters, numbers and/or underline symbols.

🏠 SYSTEM > User Management

☰ User Management

Old Password

New Password

The password must be a combination of 5 to 12 characters, numbers and underline marks

Confirm Password

Save

Cancel

☰ Session Timeout Setting

Session Timeout: (10-1440 min)

Save

Description	Default
Old Password	
Input the original password.	admin
New Password	
Input the new password you'd like to use. The password length should be 5-12 digits and is composed of lowercase letters, uppercase letters (case sensitive), numerals 0-9 and underline.	N/A
Confirm Password	
Again input the password you'd like to use to double confirm there is no typo.	A/A
Session Timeout	
Session timeout is an expired time limit for a logged in user which as been inactive for a period of time. Setting range is from 10 to 1440 minutes	30

3.4.2 Time Zone Configurations

You can change the current time of the device. Use the dropdown list to select the correct time zone for your device.

🏠 SYSTEM > Time Zone Settings

The current time of device 2019-08-27 17:10:37

Local PC Time 2019-08-27 17:10:40 Set Local PC Time

Time Zone Settings (GMT+08:00) Beijing, Chongqing, Hong Kong, Urumqi Save

Description	Default
The current time of device	
Here shows the current time of your device.	N/A
Set Local PC Time	
Configure time and date settings to be synchronized with the connected PC.	N/A
Time Zone Setting	
Select the operating time zone of your device: GMT-12:00 - GMT+13:00.	GMT+08:00

Instruction	<p>Example: Sync time between the device and the connected PC.</p> <ol style="list-style-type: none"> 1. Enter DX webpage. 2. Go to "SYSTEM -> Time Zone Settings" 3. Click "Set Local PC Time" 4. After a confirmation message prompted, click yes and reboot the device to complete synchronization.
Figure	<p>🏠 SYSTEM > Time Zone Settings</p> <p>The current time of device 2020-04-23 17:42:55</p> <p>Local PC Time 2020-04-23 17:42:54 Set Local PC Time</p> <p>Time Zone Settings (GMT+08:00) Beijing, Chongqing, Hong Kong, Urumqi Save</p>

3.4.3 RS232

RS-232 supports 7 working modes: Transparent mode, Slave mode, Master mode, Serial Server-TCP Server, Serial Server-TCP Client, Serial Server-UDP Client and MC master mode.

This section provides information of specific RS232 port parameters under different working modes. The basic parameters are presented in the table below.

Description	Default
Working Mode	
Select the working mode for the current active serial port.	Close
Baud Rate	
Set up the baud rate for the serial port. Options are 2400, 4800, 9600, 19200, 38400, 57600 and 115200.	9600
Data Bits	
Set up the data bits for the serial port. Options are 7 and 8. It must be set to 8 when communication mode is Modbus RTU.	8
Stop Bits	
Set up the stop bits for the serial port. Options are 1 and 2.	1
Parity Bits	
Set up the parity bits for the serial port. Options are None, Odd and Even.	None
Flow Control	
Set up the flow control. Options are None, XON, XOFF, RTS, and CTS.	None

- **Transparent mode**

When RS-232 is under transparent mode, users can debug devices and upload/ download data remotely by creating virtual serial ports via DIACom.

☰ RS232

Working Mode	Transparent mode ▼
Baud Rate	9600 ▼
Data Bits	8 ▼
Stop Bits	1 ▼
Parity Bits	None ▼
Flow Control	None ▼

- **Slave mode**

This mode is for the master device to perform the read/ write tasks on the open register of DX router to achieve bidirectional data transmission.

☰ RS232

Working Mode	<input type="text" value="Slave mode"/>
Baud Rate	<input type="text" value="9600"/>
Data Bits	<input type="text" value="8"/>
Stop Bits	<input type="text" value="1"/>
Parity Bits	<input type="text" value="None"/>
Flow Control	<input type="text" value="None"/>
Slave ID	<input type="text" value="1"/>
Mode	<input type="text" value="Modbus RTU"/>
Timeout	<input type="text" value="200"/> (ms)

Save

Cancel

Description	Default
Slave ID	
Set up the MODBUS ID. The value is between 1 and 247.	1
Mode	
Set up the communication mode for the device. Device support Modbus RTU and Modbus ASCII	Modbus RTU
Timeout	
Set up the timeout timer from 200ms to 5000ms. If the set value is out of range, it will be automatically changed to its maximum or minimum value.	200ms

• **Master mode**

In this mode, it is allowable for DX router to perform the read/ write tasks on the open register of the slave device via RS-232 to achieve bidirectional data transmission.

☰ **RS232**

Working Mode

Baud Rate

Data Bits

Stop Bits

Parity Bits

Flow Control

Slave ID

Mode

Timeout (ms)

Read/Write Configuration

Scan Interval (ms)

When communicate with PLC of Delta, the starting address can be set as the internal register number. For example, input 0 for register D0.

The acceptable address range of this device is: \$0-\$1535 or \$2048-\$4095 or M0-M511.

Row Number	Read/Write	Slave ID	Controller	Address Type	Slave Starting Address	Bit	Device Starting Address	Length (1-123)	Operation
1	Read/Write	1	Delta DVP PLC	D		0	\$		<input type="button" value="+"/> <input type="button" value="-"/>

Description	Default
Slave ID	
Set up the MODBUS ID for DX router. Invalid in Master mode.	1
Mode	
Set the communication mode for the device. Device support Modbus RTU and Modbus ASCII.	Modbus RTU
Timeout	
Set the timeout timer from 200ms to 5000ms. If the set value is out of range, it will be automatically changed to its maximum or minimum value.	200ms
Scan Interval	
Set the time for scan interval, ranging from 50ms to 60000ms.	30000ms

Description	Default
Add Mappings	
Click the button to add mappings. After creating a mapping between IP addresses of slave device and DX router under the user's configuration, the system will collect data from the slave device.	N/A
Delete All Mappings	
Delete all the existing mapping under the master mode of RS-232.	N/A
Export Configure List	
Export all the mapping and save as a file in the local PC.	N/A
Import Configure List	
<p>This function supports communication interfaces including RS232/RS485/MODBUS TC/MC/SIEMEN TCP, which share a total of 600 mapping web addresses.</p> <p> Notice:</p> <ul style="list-style-type: none"> Each communication interface can import up to 600 mapping addresses. However, if RS232 has been mapped to 10 addresses and another 600 mapping addresses are imported, the 10 mapping address imported previously will be covered. If 10 addresses has been mapping to RS232, there would be only 590 addresses left for RS485/MODBUS/TCP communication interfaces to import. A warning message will be displayed if exceeds the limit. 	N/A
Read/Write	
<p>Set up the access permissions for the mapped register address;</p> <ul style="list-style-type: none"> Read-only: The device regular read data from appointed registers in the slave, but will not update the data to the slave Write-only: The device updates the data to the slave when the registers values were changed, but will not read the data from the slave Read/write: The device regular read data from appointed registers in the slave, will update the data to the slave when the registers values are changed. 	Read/Write
Slave ID	
Set up the corresponding slave communication port. The value is between 1 and 247.	1
Controller	
<p>In master mode, device types options are:</p> <ul style="list-style-type: none"> Delta PLC: Use this option for Delta DVP / AH / AS series PLCs Other: Use this option for non-Delta PLCs. HEX means hexadecimal address; DEC means decimal address. 	Delta DVP PLC

Description	Default
Address Type	
<p>In master mode, the address type would changes with different options of controller type:</p> <ul style="list-style-type: none"> • Delta PLC: address types would be D/M/S/X/Y, which D is a word type and M/S/X/Y are of bit type. • Other: Address type is 0x/1x/3x/4x/Swap <ul style="list-style-type: none"> a) 0x: Coils(Modbus function code: 01/05), read-write. b) 1x: Discrete Inputs(Modbus function code: 02), read only. c) 3x: Input Registers (Modbus function code: 04) , read only. d) 4x: Holding Registers (Modbus function code: 03/16), read-write. e) Swap: If using “double words” to read/write “holding registers”, before reading or writing, the values in Hi Word and Low Word will be swapped first. 	D
Slave Starting Address (decimal)	
<p>Set up the slave starting address for read/write the registers in a PLC.</p> <ul style="list-style-type: none"> • Delta PLC: Enter the internal D register number. If you need to read / write D0, please enter 0 here. • Other: Enter the Hexadecimal or Decimal actual address. For example: Holding Register: 400100, take 0100 (decimal) that is 64 (hex). 	N/A
Bit	
<p>For the X/Y type of Delta AH/AS series, the address input format is 0.0~X.15. Enter the values before decimal point in the input field of Slave Starting Address; values after decimal point should be entered in the input field of Bit.</p>	N/A
Device Starting Address (decimal)	
<p>Set up the device starting address (decimal, word-type input range is from \$2048 to \$4095; bit-type input range is from M0 to M511). Must start at the beginning of a Device Starting Address with a “\$” or “M”.</p>	N/A
Length (1-123)	
<p>Set the length which is the number of continuous addresses followed by the starting address which will be read or write, ranging from 1 to 123.</p>	N/A
Operation	
<p>Click the +/- button to add mapping or delete mapping.</p>	N/A
Edit	
<p>Click an item of register mapping forms that can be edited.</p>	N/A

- **Serial Server-TCP Server**

In this working mode, DX series routers working as TCP servers receive data packets from clients, then send to RS-232 after parsing.

RS232

Working Mode	<input type="text" value="Serial Server - TCP Server"/>
Baud Rate	<input type="text" value="9600"/>
Data Bits	<input type="text" value="8"/>
Stop Bits	<input type="text" value="1"/>
Parity Bits	<input type="text" value="None"/>
Flow Control	<input type="text" value="None"/>
TCP Alive Check Time	<input type="text" value="7"/> (0-99 min)
Listening Port	<input type="text" value="16000"/>
Packing Length	<input type="text" value="0"/> (0-1024)
Force Transmit	<input type="text" value="0"/> (0-65535 ms)

Description	Default
TCP Alive Check Time	
Setting how long TCP activity keep idle, then the TCP connection will be drop. Input range is from 0 to 99 minutes. 0 means will never drop it.	7
Listening Port	
Set up the listening port in server.	16000
Packing Length	
Setting the length of packet, packet will be transmitted when the size reaches the values. Input range is from 0 to 1024 byte. 0 means will transmit at once when received the data.	0
Force Transmit	
Setting how long the program waiting, then transmit the packet. Input range is from 0 to 65535 millisecond. 0 means will never force to transmit.	0

• **Serial Server-TCP Client**

Under this mode, DX routers will be clients of device servers to send data with a TCP connection.

☰ **RS232**

Working Mode	<input type="text" value="Serial Server - TCP Client"/>		
Baud Rate	<input type="text" value="9600"/>		
Data Bits	<input type="text" value="8"/>		
Stop Bits	<input type="text" value="1"/>		
Parity Bits	<input type="text" value="None"/>		
Flow Control	<input type="text" value="None"/>		
TCP Alive Check Time	<input type="text" value="7"/>	(0-99 min)	
Destination IP Address1	<input type="text" value="192.168.5.100"/>	Port	<input type="text" value="4001"/>
Destination IP Address2	<input type="text"/>	Port	<input type="text" value="4002"/>
Destination IP Address3	<input type="text"/>	Port	<input type="text" value="4003"/>
Destination IP Address4	<input type="text"/>	Port	<input type="text" value="4004"/>
Designated Local Port1	<input type="text" value="14001"/>		
Designated Local Port2	<input type="text" value="14002"/>		
Designated Local Port3	<input type="text" value="14003"/>		
Designated Local Port4	<input type="text" value="14004"/>		
Packing Length	<input type="text" value="0"/>	(0-1024)	
Force Transmit	<input type="text" value="0"/>	(0-65535 ms)	

Description	Default
TCP Alive Check Time	
Configure the duration of idle state before disconnect TCP automatically. Selectable values: 0~99 -0 : Never shut off TCP connection due to idle state. -1~99 : Shut off when the duration of idle state reaches the setting value.	7
Destination IP address and Port	
Set up destination IP addresses and ports. (Default:4001~4004, configurable) IP addresses and ports cannot be duplicated with a maximum of 4 servers allowed to be connected at the same time.	Default port 4001~4004

Description	Default
Designated local port	
Set up the local port for transmission.	14001~14004
Packing Length	
Setting the length of packet, packet will be transmitted when the size reaches the values. Input range is from 0 to 1024 byte. 0 means will transmit at once when received the data.	0
Force Transmit	
Configure the length of time awaiting to transmit a data packet forcibly, ranging 0~65535ms. When reaches the setting of time duration or the length of accumulated data, the data would be transmitted immediately. If set as 0, no data packet would be sent.	0

3

- **Serial Server-UDP Client**

Under this mode, DX routers will be clients of device servers to send data with a UDP connection.

 **RS232**

Working Mode	Serial Server - UDP Client ▾		
Baud Rate	9600 ▾		
Data Bits	8 ▾		
Stop Bits	1 ▾		
Parity Bits	None ▾		
Flow Control	None ▾		
	Begin	End	port
Destination IP Address1	<input type="text"/>	<input type="text"/>	: 6001
Destination IP Address2	<input type="text"/>	<input type="text"/>	: 6002
Destination IP Address3	<input type="text"/>	<input type="text"/>	: 6003
Destination IP Address4	<input type="text"/>	<input type="text"/>	: 6004
Local Listen Port	<input type="text" value="15000"/>		
Packing Length	<input type="text" value="0"/>	(0-1024)	
Force Transmit	<input type="text" value="0"/>	(0-65535 ms)	

3

Description	Default
Destination IP address and Port	
Set the destination IP addresses and ports. (Default:6001~6004, configurable) IP addresses and ports cannot be duplicated with a maximum of 4 servers allowed to be connected at the same time. Each server can support up to 99 addresses, counting from the starting address.	Default port 6001~6004
Local listen port	
Set up the local port for transmission.	15000
Packing Length	
Setting the length of packet, packet will be transmitted when the size reaches the values. Input range is from 0 to 1024 byte. 0 means will transmit at once when received the data.	0
Force Transmit	
Set the length of time awaiting to transmit a data packet forcibly, ranging 0~65535ms. When reaches the setting of time duration or the length of accumulated data, the data would be transmitted immediately. If set as 0, no data packet would be sent.	0

• **MC master mode**

When RS232 is in MC master mode, DX series routers can perform the read/ write tasks on the slave device of Mitsubishi PLC FX series via RS232 to achieve bidirectional data transmission.

☰ **RS232**

Working Mode

Baud Rate

Data Bits

Stop Bits

Parity Bits

Flow Control

Slave ID

Mode

Timeout (ms)

Read/Write Configuration

Scan Interval (ms)

The acceptable address range of this device is: \$0-\$1535 or \$2048-\$4095 or M0-M511.

Row Number	Read/Write	Slave ID	Controller	Address Type	Slave Starting Address	Bit	Device Starting Address	Length (1-64)	Operation
1	Read/Write	0	MITSUBISHI PLC	D		0	\$		<input type="button" value="+"/> <input type="button" value="-"/>

Description	Default
Slave ID	
Set up the MODBUS ID for DX router. Invalid in MC Master mode.	0
Mode	
It's fixed to "MC ASCII" in MC master mode.	MC ASCII
Timeout	
Set the timeout timer from 200ms to 5000ms according to the actual situation. If the set value is out of range, it will be automatically changed to its maximum or minimum value.	200ms
Scan Interval	
Set up the time for scan interval, ranging from 50ms to 60000ms.	30000ms
Add Mappings	
Click the button to add mappings. After creating a mapping between IP addresses of slave device and DX router under the user's configuration, the system will collect data from the slave device.	N/A
Delete All Mappings	
Delete all the existing mapping under the master mode of RS-232.	N/A
Export Configure List	
Export all the mapping and save as a file in the local PC.	N/A
Import Configure List	
<p>This function supports communication interfaces including RS232/RS485/MODBUS TC/MC/SIEMEN TCP, which share a total of 600 mapping web addresses.</p> <p> Notice:</p> <ul style="list-style-type: none"> Each communication interface can import up to 600 mapping addresses. However, if RS232 has been mapped to 10 addresses and another 600 mapping addresses are imported, the 10 mapping address imported previously will be covered. If 10 addresses has been mapping to RS232, there would be only 590 addresses left for other communication interfaces to import. A warning message will be displayed if exceeds the limit. 	N/A
Read/Write	
<p>Set up the access permissions for the mapped register address;</p> <ul style="list-style-type: none"> Read-only: The device regular read data from appointed registers in the slave, but will not update the data to the slave Write-only: The device updates the data to the slave when the registers values were changed, but will not read the data from the slave Read/write: The device regular read data from appointed registers in the slave, will update the data to the slave when the registers values are changed. 	Read/Write
Slave ID	
It's fixed to 0 in MC master mode.	0

Description	Default
Controller	
It's fixed to "MITSUBISHI PLC" in MC master mode.	MITSUBISHI PLC
Address Type	
Address types would be D/M/S/X/Y, which D is a word type and M/S/X/Y are bit types.	D
Slave Starting Address (decimal)	
Set the slave starting address for the registers under read/write task, inputting the number of the internal D register. (Input 0 for D0)	N/A
Bit	
Invalid under MC master mode.	N/A
Device Starting Address (decimal)	
Set up the device starting address (decimal, input range is from \$2048 to \$4095 for word type data, input range is from M0 to M511 for bit type data). \$ or M specifies that the match must start at the beginning of a Device Starting Address.	N/A
Length	
Set up the number of the continuous address followed by the default mapped address will be read or write. Input range is from 1 to 64.	N/A
Operation	
Click the +/- button to add mapping or delete mapping.	N/A
Edit	
Click an item of register mapping forms that can be edited.	N/A

3.4.4 RS485

RS-485 supports 6 working modes: Transparent mode, Slave mode, Master mode, Serial Server-TCP Server, Serial Server-TCP Client and Serial Server-UDP Client. This section provides information of specific RS-485 port parameters under different working modes. The basic parameters are presented in the table below.

Description	Default
Working Mode	
Select the working mode for the current active serial port.	Close
Baud Rate	
Set up the baud rate for the serial port. Options are 2400, 4800, 9600, 19200, 38400, 57600 and 115200.	9600
Data Bits	
Set port data bits as 7 or 8. When operating in Modbus RTU mode, the value can only be set as 8.	8
Stop Bits	
Set up the stop bits for the serial port. Options are 1 and 2.	1

Description	Default
Parity Bits	
Set up the parity bits for the serial port. Options are None, Odd and Even.	None

- **Transparent mode**

When RS-485 is under transparent mode, users can debug devices and upload/ download data remotely by creating virtual serial ports via DIACom.

RS485

Working Mode	Transparent mode ▾
Baud Rate	9600 ▾
Data Bits	8 ▾
Stop Bits	1 ▾
Parity Bits	None ▾

- **Slave mode**

This mode is for the master device to perform the read/ write tasks on the open register of DX routers to achieve bidirectional data transmission.

RS485

Working Mode	Slave mode ▾
Baud Rate	9600 ▾
Data Bits	8 ▾
Stop Bits	1 ▾
Parity Bits	None ▾
Slave ID	1
Mode	Modbus RTU ▾
Timeout	200 (ms)

3

Description	Default
Slave ID	
Set up the MODBUS ID. The value is between 1 and 247.	1
Mode	
Set up the communication mode for the device. Device support Modbus RTU and Modbus ASCII	Modbus RTU
Timeout	
Set up the timeout timer from 200ms to 5000ms. If the set value is out of range, it will be automatically changed to its maximum or minimum value.	200ms

• **Master mode**

In this mode, it is allowable for DX router to perform the read/ write tasks on the slave device via an RS-485 connection to achieve bidirectional data transmission.

☰ **RS485**

Working Mode

Baud Rate

Data Bits

Stop Bits

Parity Bits

Slave ID

Mode

Timeout (ms)

Read/Write Configuration

Scan Interval (ms)

When communicate with PLC of Delta, the starting address can be set as the internal register number. For example, input 0 for register D0.

The acceptable address range of this device is: \$0-\$1535 or \$2048-\$4095 or M0-M511.

Row Number	Read/Write	Slave ID	Controller	Address Type	Slave Starting Address	Bit	Device Starting Address	Length (1-123)	Operation
1	Read/Write	1	Delta DVP PLC	D		0	\$		<input type="button" value="+"/> <input type="button" value="-"/>

Description	Default
Slave ID	
Set up the MODBUS ID for DX router. Invalid in Master mode.	1
Mode	
Set up the communication mode for the device. Device support Modbus RTU and Modbus ASCII.	Modbus RTU
Timeout	
Set up the timeout timer from 200ms to 5000ms. If the set value is out of range, it will be automatically changed to its maximum or minimum value.	200ms
Scan Interval	
Set up the time for scan interval, ranging from 50ms to 60000ms.	30000ms
Add Mappings	
Click the button to add mappings. After creating a mapping between IP addresses of slave device and DX router under the user's configuration, the system will collect data from the slave device.	N/A
Delete All Mappings	
Delete all the existing mapping under the master mode of RS-485.	N/A
Export Configure List	
Export all the mapping and save as a file in the local PC.	N/A
Import Configure List	
<p>This function supports communication interfaces including RS232/RS485/MODBUS TC/MC/SIEMEN TCP, which share a total of 600 mapping web addresses.</p> <p> Notice:</p> <ul style="list-style-type: none"> Each communication interface can import up to 600 mapping addresses. However, if RS485 has been mapped to 10 addresses and another 600 mapping addresses are imported, the 10 mapping address imported previously will be covered. If 10 addresses has been mapping to RS485, there would be only 590 addresses left for other communication interfaces to import. A warning message will be displayed if exceeds the limit. 	N/A
Read/Write	
<p>Set up the access permissions for the mapped register address;</p> <ul style="list-style-type: none"> Read-only: The device regular read data from appointed registers in the slave, but will not update the data to the slave Write-only: The device updates the data to the slave when the registers values were changed, but will not read the data from the slave Read/write: The device regular read data from appointed registers in the slave, will update the data to the slave when the registers values are changed. 	Read/Write
Slave ID	
Set up the corresponding slave communication port. The value is between 1 and 247.	1

Description	Default
Controller	
In master mode, device types options are: <ul style="list-style-type: none"> Delta PLC: Use this option for Delta DVP / AH / AS series PLCs Other: Use this option for non-Delta PLCs. HEX means hexadecimal address; DEC means decimal address. 	Delta DVP PLC
Address Type	
In master mode, the address type would changes with different options of controller type.: <ul style="list-style-type: none"> Delta PLC: address types would be D/M/S/X/Y, which D is a word type and M/S/X/Y are of bit type. Other: Address type is 0x/1x/3x/4x/Swap <ol style="list-style-type: none"> 0x: Coils(Modbus function code: 01/05), read-write. 1x: Discrete Inputs(Modbus function code: 02), read only. 3x: Input Registers (Modbus function code: 04) , read only. 4x: Holding Registers (Modbus function code: 03/16), read-write. <ol style="list-style-type: none"> Swap: If using “double words” to read/write “holding registers”, before reading or writing, the values in Hi Word and Low Word will be swapped first. 	D
Slave Starting Address (decimal)	
Set up the slave starting address for read/write the registers in a PLC. <ul style="list-style-type: none"> Delta PLC: Enter the internal D register number. If you need to read / write D0, please enter 0 here. Other: Enter the Hexadecimal or Decimal actual address. For example: Holding Register: 400100, take 0100 (decimal) that is 64 (hex). 	N/A
Bit	
For the X/Y type of Delta AH/AS series, the address input format is 0.0~X.15. Enter the values before decimal point in the input field of Slave Starting Address, while values after decimal point should be entered in the input field of Bit.	N/A
Device Starting Address (decimal)	
Set up the device starting address (decimal, input range is from \$2048 to \$4095). Bit type range is M0~M511. The beginning of a Device Starting Address must starts with a “\$” or “M”.	N/A
Length (1-123)	
Set up the number of the continuous address followed by the default mapped address will be read or write. Input range is from 1 to 64.	N/A
Operation	
Click the +/- button to add mapping or delete mapping.	N/A
Edit	
Click an item of register mapping forms that can be edited.	N/A

- **Serial Server-TCP Server**

In this working mode, DX series routers working as TCP servers receive data packets from clients, then send to RS-485 after parsing.

RS485

Working Mode	<input type="text" value="Serial Server - TCP Server"/>
Baud Rate	<input type="text" value="9600"/>
Data Bits	<input type="text" value="8"/>
Stop Bits	<input type="text" value="1"/>
Parity Bits	<input type="text" value="None"/>
TCP Alive Check Time	<input type="text" value="7"/> (0-99 min)
Listening Port	<input type="text" value="16000"/>
Packing Length	<input type="text" value="0"/> (0-1024)
Force Transmit	<input type="text" value="0"/> (0-65535 ms)

Save

Cancel

Description	Default
TCP Alive Check Time	
Configure the duration of the idle state before disconnect TCP automatically. Selectable values: 0~99 -0 : Never shut off TCP connection due to idle state. -1~99: Disconnect TCP once the duration reaches the setting value.	7
Listening Port	
Set the listening port of the server.	16000
Packing Length	
Set the length of the accumulated data for packets sending, ranging 0~1024 bytes. Set as 0 for real-time data transmission.	0
Force Transmit	
Set the length of time awaiting to transmit a data packet, ranging 0~65535 ms. When reaches the setting of time duration or the length of accumulated data, the data would be transmitted immediately. If set as 0, no data packet would be sent.	0

• **Serial Server-TCP Client**

Under this mode, DX routers will be clients of device servers to send data with a TCP connection.

 **RS485**

3

Working Mode	<input type="text" value="Serial Server - TCP Client"/>	
Baud Rate	<input type="text" value="9600"/>	
Data Bits	<input type="text" value="8"/>	
Stop Bits	<input type="text" value="1"/>	
Parity Bits	<input type="text" value="None"/>	
TCP Alive Check Time	<input type="text" value="7"/>	(0-99 min)
Destination IP Address1	<input type="text" value="192.168.5.100"/>	Port <input type="text" value="4001"/>
Destination IP Address2	<input type="text"/>	Port <input type="text" value="4002"/>
Destination IP Address3	<input type="text"/>	Port <input type="text" value="4003"/>
Destination IP Address4	<input type="text"/>	Port <input type="text" value="4004"/>
Designated Local Port1	<input type="text" value="14001"/>	
Designated Local Port2	<input type="text" value="14002"/>	
Designated Local Port3	<input type="text" value="14003"/>	
Designated Local Port4	<input type="text" value="14004"/>	
Packing Length	<input type="text" value="0"/>	(0-1024)
Force Transmit	<input type="text" value="0"/>	(0-65535 ms)

Description	Default
TCP Alive Check Time	
Configure the duration of the idle state before disconnect TCP automatically. Selectable values: 0~99 -0 : Never shut off TCP connection due to idle state. -1~99: Disconnect TCP once the duration reaches the setting value.	7
Destination IP address and Port	
Set the destination IP addresses and ports. (Default:4001~4004, configurable) IP addresses and ports cannot be duplicated with a maximum of 4 servers allowed	4001~4004

Description	Default
to be connected at the same time.	
Designated local port	
Set local ports for your device.	14001~14004
Packing Length	
Set the length of the accumulated data for packets sending, ranging 0~1024 bytes. Set as 0 for real-time data transmission.	0
Force Transmit	
Set the length of time awaiting to transmit a data packet, ranging 0~65535 ms. When reaches the setting of time duration or the length of accumulated data, the data would be transmitted immediately. If set as 0, no data packet would be sent.	0

- **Serial Server-UDP Client**

Under this mode, DX routers will be clients of device servers to send data with a UDP connection.

RS485

Working Mode	Serial Server - UDP Client ▾		
Baud Rate	9600 ▾		
Data Bits	8 ▾		
Stop Bits	1 ▾		
Parity Bits	None ▾		
	Begin	End	port
Destination IP Address1	<input type="text"/>	<input type="text"/>	: <input type="text" value="6001"/>
Destination IP Address2	<input type="text"/>	<input type="text"/>	: <input type="text" value="6002"/>
Destination IP Address3	<input type="text"/>	<input type="text"/>	: <input type="text" value="6003"/>
Destination IP Address4	<input type="text"/>	<input type="text"/>	: <input type="text" value="6004"/>
Local Listen Port	<input type="text" value="15000"/>		
Packing Length	<input type="text" value="0"/>	(0-1024)	
Force Transmit	<input type="text" value="0"/>	(0-65535 ms)	

Description	Default
Destination IP address and Port	
Set the destination IP addresses and ports. (Default:6001~6004, configurable) IP addresses and ports cannot be duplicated with a maximum of 4 servers allowed to be connected under UDP at the same time. Each server can support up to 99 addresses, counting from the starting address.	6001~6004
Local listen port	
Set the local listen port for your device.	15000
Packing Length	
Set the length of the accumulated data for packets sending, ranging 0~1024 bytes. Set as 0 for real-time data transmission.	0
Force Transmit	
Set the length of time awaiting to transmit a data packet, ranging 0~65535 ms. When reaches the setting of time duration or the length of accumulated data, the data would be transmitted immediately. If set as 0, no data packet would be sent.	0

3.4.5 Modbus TCP

This page allows users to set whether to enable Modbus TCP client mode and set relevant parameters.

🏠 SYSTEM > Modbus TCP

☰ Modbus TCP

Working Mode

Modbus TCP Server+Client ▾

Confirm

*32 modbus TCP servers supported at most

Add Server

Row Number	Server IP	Server Port	Response Timeout(ms)	Scan Interval(ms)	Operation
------------	-----------	-------------	----------------------	-------------------	-----------

Modbus TCP Client Setting

Server IP

Server Port

Response Timeout (ms)

Read/Write Configuration

Scan Interval (ms)

When communicate with PLC of Delta, the starting address can be set as the internal register number. For example, input 0 for register D0.

The acceptable address range of this device is: \$0-\$1535 or \$2048-\$4095 or M0-M511.

Make sure that the server already exists before importing, otherwise the importing is invalid and it will return to the original state.

Row Number	Read/Write	Slave ID	Controller	Address Type	Slave Starting Address	Bit	Device Starting Address	Length (1-123)	Operation
1	Read/Write ▾	1	Delta DVP PLC ▾	D ▾		0	\$		<input type="button" value="+"/> <input type="button" value="-"/>

Description	Default
Working Mode	
<ul style="list-style-type: none"> Modbus TCP Server: Only Modbus TCP server works. And supports up to 32 Client to connect. Modbus TCP Server+Client: Modbus TCP server + Modbus TCP client work at the same time. MODBUS TCP Client supports to connect to 32 different servers at most. 	Modbus TCP Server
Server IP	
Set up the IP address of a PLC in the Modbus TCP Client mode	N/A
Server Port	
Set up the server port of a PLC in the Modbus TCP Client mode	502
Response Timeout	
Set up the timeout timer from 50ms to 10000ms. If the set value is out of range, it will be automatically changed to its maximum or minimum value. The default is 300ms.	300
Scan Interval	
Set up the time for scan interval, ranging from 50ms to 60000ms; the default is 3000ms.	30000
Add Mappings	
Click the button to add mappings. After creating a mapping between IP addresses of slave device and DX router under the user's configuration, the system will collect data from the slave device.	N/A
Delete All Mappings	
Delete all the existing mapping of the device.	N/A

Description	Default
Export Configure List	
Export all the mapping and save as a file in the local PC.	N/A
Import Configure List	
<p>This function supports communication interfaces including RS232/ RS485/ MODBUS TC/ MC/ SIEMEN TCP, which share a total of 600 mapping web addresses.</p> <p> Notice:</p> <ul style="list-style-type: none"> Each communication interface can import up to 600 mapping addresses. However, if RS232 has been mapped to 10 addresses and another 600 mapping addresses are imported, the 10 mapping address imported previously will be covered. If 10 addresses has been mapping to RS232, there would be only 590 addresses left for other communication interfaces to import. A warning message will be displayed if exceeds the limit. 	N/A
Read/Write	
<p>Set up the access permissions for the mapped register address;</p> <ul style="list-style-type: none"> Read-only: The device regular read data from appointed registers in the slave, but will not update the data to the slave Write-only: The device updates the data to the slave when the registers values were changed, but will not read the data from the slave Read/write: The device regular read data from appointed registers in the slave, will update the data to the slave when the registers values are changed. 	Read/Write
Slave ID	
Set up the corresponding slave communication port. The value is between 1 and 247.	1
Controller	
<p>In master mode, device types options are:</p> <ul style="list-style-type: none"> Delta PLC: Use this option for Delta DVP / AH / AS series PLCs Other: Use this option for non-Delta PLCs. HEX means hexadecimal address; DEC means decimal address. 	Delta DVP PLC
Address Type	
<p>In master mode, the address type would changes with different options of controller type.:</p> <ul style="list-style-type: none"> Delta PLC: address types would be D/M/S/X/Y, which D is a word type and M/S/X/Y are of bit type. Other: Address type is 0x/1x/3x/4x/Swap <ol style="list-style-type: none"> 0x: Coils(Modbus function code: 01/05), read-write. 1x: Discrete Inputs(Modbus function code: 02), read only. 3x: Input Registers (Modbus function code: 04) , read only. 4x: Holding Registers (Modbus function code: 03/16), read-write. 	D

Description	Default
e) Swap: If using "double words" to read/write "holding registers", before reading or writing, the values in Hi Word and Low Word will be	
Slave Starting Address (decimal)	
Set up the slave starting address for read/write the registers in a PLC. <ul style="list-style-type: none"> Delta PLC: Enter the internal D register number. If you need to read / write D0, please enter 0 here. Other: Enter the Hexadecimal or Decimal actual address. For example: Holding Register: 400100, take 0100 (decimal) that is 64 (hex). 	N/A
Bit	
For the X/Y type of Delta AH/AS series, the address input format is 0.0~X.15. Enter the values before decimal point in the input field of Slave Starting Address, while values after decimal point should be entered in the input field of Bit.	
Device Starting Address (decimal)	
Set up the device starting address (decimal, input range is from \$2048 to \$4095 for word type data, input range is from M0 to M511 for bit type data). \$ or M specifies that the match must start at the beginning of a Device Starting Address.	N/A
Length (1-123)	
Set the number of the continuous address followed by the starting address which will be read or write. Input range is from 1 to 123.	N/A
Operation	
Click the +/- button to add mapping or delete mapping.	N/A
Edit	
Click an item of register mapping forms that can be edited.	N/A

3.4.6 Siemens TCP

Support Siemens TCP Client mode to perform data exchange with Siemens S7-300/S7-1200/S7-1500 through Ethernet.

🏠 SYSTEM > Siemens TCP

☰ Siemens TCP Client

*32 Siemens TCP servers supported at most

Add Server

Row Number	Server IP	Controller	Response Timeout(ms)	Scan Interval(ms)	Operation
------------	-----------	------------	----------------------	-------------------	-----------

Click "Add Server" to enter the setting page.

Siemens TCP Client Setting

Controller ▼
 Server IP
 Response Timeout (ms)

Read/Write Configuration

Scan Interval (ms)

The acceptable address range of this device is: \$0-\$1535 or \$2048-\$4095 or M0-M511.

The length should be 1 when the data type is BIT.

Make sure that the server already exists before importing, otherwise the importing is invalid and it will return to the original state.

Row Number	Read/Write	Data Type	Address Type	DB Number	Slave Offset Address	Bit	Device Starting Address	Length (1-123)	Operation
1	Read/Write ▼	WORD ▼	DB ▼			0	\$		<input type="button" value="+"/> <input type="button" value="-"/>

Description	Default
Add Server	
Choose the target Siemens TCP server for connection to the routers with 32 servers supported at most.	NA
Controller	
Set the model type of the Siemens devices for communication.	S7-300
Server IP	
Set the IP address of the Siemens devices for communication.	N/A
Local TSAP	
Set up the address of local TSAP with Siemens ISO-on-TCP only when controller's model "S7-200 ISO TCP" or "S7-1200/1500 ISO TCP" is used.	N/A
Remote TSAP	
Set up the address of remote TSAP with Siemens ISO-on-TCP only when controller's model "S7-200 ISO TCP" or "S7-1200/1500 ISO TCP" is used.	N/A
Response Timeout	
Users can change the time-out value according to the actual situation with the acceptable time range from 50ms to 10000ms. If specified but the input value is out of the range, it will be set to the value of the min or max attribute.	300
Scan Interval	
Set up the time for scan interval, ranging from 50ms to 60000ms.	30000

Description	Default
Add Mappings	
Click the button to add mappings. After creating a mapping between IP addresses of slave device and DX router under the user's configuration, the system will collect data from the slave device.	N/A
Delete All Mappings	
Delete all the existing mappings under the server.	N/A
Export Configure List	
Export all the mapping and save as a file in the local PC.	N/A
Import Configure List	
<p>This function supports communication interfaces including RS232/ RS485/ MODBUS TC/ MC/ SIEMEN TCP, which share a total of 600 mapping web addresses.</p> <p> Notice:</p> <ul style="list-style-type: none"> Each communication interface can import up to 600 mapping addresses. However, if RS232 has been mapped to 10 addresses and another 600 mapping addresses are imported, the 10 mapping address imported previously will be covered. If 10 addresses has been mapping to RS232, there would be only 590 addresses left for other communication interfaces to import. A warning message will be displayed if exceeds the limit. 	N/A
Read/Write	
<p>Set up the access permissions for the mapped register address;</p> <ul style="list-style-type: none"> Read-only: The device regular read data from appointed registers in the slave, but will not update the data to the slave Write-only: The device updates the data to the slave when the registers values were changed, but will not read the data from the slave Read/write: The device regular read data from appointed registers in the slave, will update the data to the slave when the registers values are changed. 	Read/Write
Data Type	
<p>Set the type for collected data:</p> <ul style="list-style-type: none"> BIT: Bit type WORD: Word type WORD(SWAP) : Double words type. 	WORD
Address Type	
<ul style="list-style-type: none"> If controller's model type is "S7-200 ISO TCP", address type can be set as V/M/Q/I; combined with data types: -Bit type : VB/MB/QB/IB -Word type : VW/MW/QW/IW -DWord type : VD/MD/QD/ID If controller's model type is "S7-300" or "S7-1200/1500 ISO TCP", address type can be set as DB/M/Q/I; combined with data types: 	DB

Description	Default
-Bit type: DBn_DBX/MB/QB/IB -Word type: DBn_DBW/MW/QW/IW -DWord type: DBn_DBD/MD/QD/ID	
DB Number	
Set the DB number for the starting address of Siemens slave's register operated in read/ write tasks. Not configurable when controller's model type is "S7-200 ISO TCP".	N/A
Slave Offset Address	
Set the starting address of Siemens slave's register operated in read/ write tasks. If the address is VD100, the input value would be 100.	N/A
Bit	
The address input format is 0.0~X.7. Enter the values before decimal point in the input field of Slave Offset Address, while values after decimal point should be entered in the input field of Bit.	NA
Device Starting Address	
Set the starting address of the corresponding register. Word-type input range is from \$2048 to \$4095. Bit type range is M0~M511. The beginning of a Device Starting Address must starts with a "\$" or "M".	N/A
Length	
Set the number of the continuous address followed by the starting address which will be read or write. Input range is from 1 to 123.	N/A
Operation	
Click the +/- button to add mapping or delete mapping.	N/A
Edit	
Click an item of register mapping forms that can be edited.	N/A

3.4.7 Log Settings

This page is used for configuring the log settings, including Log to Console, Remote Log Service, Remote Log Server Address, and Port of Remote Log Server.

🏠 SYSTEM > Log Settings

☰ Log Settings

Log To Console	<input type="text" value="No"/>
Remote Log Service	<input type="text" value="Disable"/>
Remote Log Server Address	<input type="text"/>
Port Of Remote Log Server	<input type="text" value="514"/> (1~65534)

Description	Default
Log to Console	
Set up the log to the console port.	No
Remote Log Service	
Enable/disable the remote log service.	Disable
Port of Remote Log Server	
Set up the remote log server port, ranging from 1 to 65534.	514

Notice

- Remote log service is used for qualified engineers to check the device remotely when errors occurred. With this service, there is no need to log in to the device, device logs can be exported to the remote log server. The server should support the syslog protocol. When this functionality is enabled, it will take up some resources. Do not enable this functionality disabled, unless it's necessary.

3.4.8 Firmware Upgrade

This page is used for upgrading the system.

SYSTEM > Firmware Upgrade

Firmware Upgrade

DO NOT turn off the power supply or reboot the device during the upgrade process. Please select the correct firmware package which is consistent with the device model, otherwise the device may be damaged !

(Before upgrade the firmware, please backup the settings and data. Please contact the local dealers or manufacturers when failed to upgrade the firmware)

Select Firmware

Description	Default
Select Firmware	
Click "Browse" to select the new firmware file.	N/A
Upgrade	
Click "Upgrade" to upgrade firmware. The device will reboot after the upgrade is done.	N/A

3.4.9 Backup & Restore

This page is used for backing up and restoring the configurations.

SYSTEM > Backup & Restore

Backup & Restore

Device configurations can be backed up and saved to local PC

Configuration restoration will remove the current settings in the device and restore the configurations in your .cfg file

Select .Cfg File

Configurations will be reset to the factory default settings, device will be reboot after the reset

Description	Default
Backup	
Click "Backup" to save the device configurations on your computer.	N/A
Restore	
Click "Browse" to select the backup file and then click "Restore" to restore the configurations. The device configuration will be restored to the previous version and the device will reboot after the restoring is done.	N/A

Description	Default
Restore To Factory Default	
Click "Restore To Factory Default" to reset the configurations to the factory defaults. The device will reboot after the reset is done.	N/A

3.4.10 Scheduled Jobs

This page is used for scheduling job configurations, including ADD A New Job, Export Job List, and Import Job List.

🏠 SYSTEM > Scheduled Jobs

Add A New Job
Export Job List
Import Job List
Browse...

ID	Job Name	Job Type	Timestamp	Enabled

3

3.4.11 Add A New Job

Click "Add A New Job" , and then you will see the following page. Follow the instruction to add a new scheduled job.

🏠 SYSTEM > Scheduled Jobs

Add A New Job

Job Name

Enabled Yes No

Time Configurations

Recurring Job Once Daily Weekly Monthly Yearly

Date Year Month Day

Job Type

Description	Default
Job Name	
Set up a name for your scheduled job. The name shall be composed of letters, numbers and underline, starting with a letter or number. The maximum string length is 32 bytes.	N/A
Enable	
Select "Enable" to activate this functionality.	Enable
Recurring Job	

Description	Default
The scheduled job can be done Once, Every day, Every week, or Every month. And the specific time can be further defined.	Once 01:00
Date	
Select a specific date to perform the scheduled job.	2015.01.01
Job Type	
Select one of the job type for the scheduled job. <ul style="list-style-type: none"> Restart device Enable DIACloud Service Disable DIACloud Service 	Restart device

3.4.12 Export Job List

Click "Export Job List" to export the scheduled jobs for future usage.

🏠 SYSTEM > Scheduled Jobs

Add A New Job Export Job List Import Job List Browse...				
ID	Job Name	Job Type	Timestamp	Enabled

3.4.13 Import Job List

Click "Chose file" to select the scheduled jobs file you have saved and then click "Import Job List" to import the scheduled jobs you have set before.

🏠 SYSTEM > Scheduled Jobs

Add A New Job Export Job List Import Job List Browse...				
ID	Job Name	Job Type	Timestamp	Enabled

3.4.14 Network Diagnosis

This page is used for diagnosing the network status; methods are Ping Test and Route Trace.

SYSTEM > Network Diagnosis

Network Diagnosis

Diagnosing Method

Host Name/IP Address

3

Description	Default
Diagnosing Method	
Selections are "Ping Test", "Route Trace" and "Cloud Service Diagnose".	Ping Test
Host Name/IP Address	
Setup the target domain or the IP Address. Options are www.google.com, www.yahoo.com, www.MSN.com, www.amazon.com, www.wikipedia.org, www.facebook.com, www.diacloudsolutions.com and others. When you choose others, you can input the domain/IP manually.	www.diacloudsolutions.com
<p>Notice</p> <p>This function would be disabled when the setting of diagnosing method is "Cloud Service Diagnose".</p>	
Start	
Click "Start" to start the network diagnosing. While running the network diagnosing, the settings cannot be changed.	N/A

3.4.15 Trouble shooting

Under normal conditions of network, if the connection with DIACloud has been failing over 30 mins after enabling the Trouble Shooting function, the device will begin to upload all device logs to the specific server directly for engineers to

troubleshoot remotely. If the problem persists, the time interval for the device to upload the logs is 1, 2, 4, 5, 16, and 24 and then the time interval is fixed to every 24 hours.

[🏠 SYSTEM](#) > [Trouble Shooting](#)

☰ Trouble Shooting Setting

Trouble Shooting

Enable

Save

Notice

- It is suggested to disable this function. However you should enable this function, if the engineer analyzed and advised you to, when some issues occur.

3.4.16 System Reboot

This page is used for manually rebooting the system. Click “Restart Device” and the system will reboot.

[🏠 SYSTEM](#) > [System Reboot](#)

☰ System Reboot

The network will be temporarily shut down during system reboot, please wait!

Restart Device

3.4.17 Event Management

This page is used for setting up 2 types of events, Communication Verification and Alarm Event.

- **Communication Verification:** when the slave (such as PLC) is connected with a router via MODBUS TCP or MODBUS RTU, the router checks whether the tunnel is a reliable connection-critical lock or not.

Communication verification expression between PLC and the router can be set here. The expression is the numeric expression in C, complying with the standard C programming syntax. The expression can be a single variable, a constant, or a single variable equation. The name of the variable is limited to “A”, and the expression should be something like this (A+100)*45.

🏠 SYSTEM > Event Management

☰ Event Management

Event Type

Communication verification ▼

Input Expression

Save



The expression is the numeric expression in C, the syntax complies with standard C programming syntax. The expression can be a single variable itself, or a constant, or a single variable equation. The name of the variable is limited to be "A", the expression can be: $(A+100)*45$

The operators that the expression supports are as below:

Operators	Types	Examples	Description
+	Arithmetic operator	A+100	Addition
-	Arithmetic operator	A-100	Subtraction
*	Arithmetic operator	A*100	Multiplication
/	Arithmetic operator	A/100	Division
&	Logic operator	A&A+100	Logic AND
	Logic operator	A A+100	Logic OR
()	Bracket operator	$(A+100)*45$	Change operation order
^	XOR operation	A^100	XOR operation

- **Alarm Event:** Click "Add" to set a new alarm event, input the Alarm Name, Description, Alarm Criteria, Event Interval, Repeat Times, Alarm Content and Target Receiver. Click "Details" to modify the existing alarm. Click "Delete" to delete the existing alarm. Click "Copy" to duplicate the alarm.

🏠 SYSTEM > Event Management

☰ Event Management

Event Type

Alarm event ▼



Add

Alarm Name	Alarm Description	Alarm Criteria	Target Receiver	Operation
------------	-------------------	----------------	-----------------	-----------

After clicking “Add”, the following page will show up.

🏠 SYSTEM > Event Management

☰ Alarm Event

Alarm Name

Alarm Description

Alarm Criteria

Event Interval (0~6000)minute

Repeat Times (0~999)times

Alarm Content

Target Receiver

Max support 5 reciever,use ';' to seperate the different email address

3

Description	Default
Alarm Name	
Input an alarm name. The name shall be composed of numbers, English letters, uppercase and lowercase. The maximum string length is 32 bytes.	N/A
Alarm Description	
The alarm description shall be composed of numbers, English letters, uppercase and lowercase. The maximum string length is 50 bytes.	N/A
Alarm Criteria	
The format of alarm variable is {\$number 0-4095}, the alarm criteria can be a single alarm variable, or a formula of one or several alarm criteria. For example, the formula can be: {\$2003}+{\$2004}*100/2-1.	N/A
Event Interval	
The time interval of alarm sending	0
Repeat Times	
The repeated times of alarm sending	0
Alarm Content	
Set up the information shown on the alarm contents. The content of the alarm will be sent to the target when alarm criteria are met. The information order can be self-defined.	N/A

Description	Default
<ul style="list-style-type: none"> • Time: the time when the alarm occurred • Date: the date when the alarm occurred • Name: the name of the occurred alarm • Description: the description of the occurred alarm <p>For example: Register \$2048 represents electrical voltage, the value of register \$2048 is 10, and the alarm content is set as: {Date} {Time} Voltage = {\$2048}, then the query content received by users will be: 2016/06/01 10:00:00(currently time) Voltage = 10. The maximum content length is 95 characters.</p>	
Target Receiver	
Set up the recipient. User can maintain the list by 【Control List Of Event Management】 in Privilege Management function. System only response the query from receiver list.	N/A



Notice

- {} is a special system symbol, which is used to reference system variables or system registers, like \${Time}, \${Date} or \${Number 0 - 4095}. Please use it with caution.

3.4.18 Register Management

This page is used for setting up the rules of register data upload to Cloud. Click “Add” to set a new rule. Click “Edit” to modify the existing rule. Click “Delete” to delete the existing rule.

🏠 SYSTEM > Register Management

		Add	Export Configure List	Import Configure List	浏览...
ID	Register Start Address	Length	Upload To Cloud	History Data	
1	\$2048	10	Yes	No	Edit Delete

The address segment 2048~4095 can be self-defined. The Start address, Length, Uploaded to Cloud or not and keep history or not can be set up.

After clicking “Add”, the following page will show up.

🏠 SYSTEM > Register Management

☰ **Add**

Register Type

Register Address (\$2048-4095, M0-511)

Length

Uploaded To Cloud

Keep History

[Save](#) [Back](#)

Description	Default
Export Configure List	
Export the configure list to the file and save to local PC	N/A
Import Configure List	
Import configure list from the local PC.  Notice: Up to 20 mappings can be imported. If a total of 10 addresses have been mapped and another 20 mapping addresses are imported, the 10 mapping address imported previously will be covered.	N/A
Register Type	
Set up the register data type, options are "Word" and "Bit".	Word
Register Start Address	
Set Register Start Address applicable for rules. Word-type addresses start with "\$", configurable from \$2048~\$4095. Bit-type addresses start with "M", configurable from M0~M511.	N/A
Length	
Set the number of the effective register address followed by the start address. Input value as 1 indicates one register. Word-type effective range: 1-2048. Bit-type effective range: 1-512.	N/A
Uploaded To Cloud	
是否将这些寄存器的值上传到云端，可选项：“是”和“否”，默认选项“是”。	Yes
Keep History Data	
This function will keep or overwrite the history data when the register values are uploaded to Cloud. <ul style="list-style-type: none"> ● Yes: The existed register values in the cloud WON'T be overwritten by the new uploaded register values. ● No: The existed register values in the cloud CAN be overwritten by the new uploaded register values. 	No

Notice

- When the values in the register changes, the results will be uploaded to cloud.

3.5 Cloud Service

3.5.1 Cloud Configurations

In this page, user can assign the cloud account which will be used to connect to DIACloud by device. Input the user name, the password and click "Verify". Refer to Chapter 4 for DIACloud account registration.

1. Login with your DIACloud account then click the "Verify" button to authenticate with DIACloud server.

🏠 CLOUD SERVICE > Cloud Configurations

☰ Cloud Configurations

User Name:

Password:

- After authentication successfully, the cloud configurations will show up then the user can modify the secure tunnel and device name.

🏠 CLOUD SERVICE > Cloud Configurations

☰ Cloud Configurations

User Name:

Password:

Secure Tunnel: ▼

Device Name:

Secure Tunnel DHCP: Available

When secure tunneling DHCP server is available, and the IP address is allocated by the DHCP server in secure tunnel network, the IP address of this device can be found in the cloud portal

Get IP From Cloud: ▼

Network Protocol: ▼

- The user also can set IP address manually.

Get IP From Cloud ▼

Cloud IP Range: 192.168.200.100 - 192.168.200.200

Cloud Netmask: 255.255.255.0

Device IP:


(Device IP should be in the same subnet with cloud IP)

- Click the "Bind" button, the DX router will bind with DIACloud server and establishes a secure tunnel between the DIACloud server and the DX router. Meanwhile a new IP will assign to DX router from DIACloud server (assign from the cloud DHCP server or a user specified).

🏠 CLOUD SERVICE > Cloud Configurations

Cloud account register success, starting secure tunnel,please wait.....

- 5. Your browser will access to the DX router with new IP address automatically if DIACloud account binds with DIACloud server successfully. Please make sure a PC and DX router are in the same subnet; otherwise PC will not be able to access to the DX router.



- 6. If the network is in the poor condition, The binding process could be successfully but the Service Status is shown "Disable".

🏠 CLOUD SERVICE > Cloud Configurations

User Name:	██████████5@163.com	
Registration Status:	Registered	<input type="button" value="Unbind"/>
Service Status:	Disabled	<input type="button" value="Enable"/>
Secure Tunnel:	default	
Device Name:	DX2300_B324	
Secure Tunnel DHCP:	Not available	
Device IP:	192.168.5.5	
Network Protocol:	<input type="text" value="UDP"/>	

- 7. In this situation, the browser will access to 192.168.1.1 and the service status will be "Disable". You can re-enable the service status to rebuild the secure tunnel again in cloud configurations.

8. When the service status is shown “Enable”, that means the DIACloud service is activated on DX-2300LN-WW. The user also can get the related information in cloud platform.

 [CLOUD SERVICE](#) > [Cloud Configurations](#)

User Name:	 @163.com	
Registration Status:	Registered	Unbind
Service Status:	Enabled	Disable
Secure Tunnel:	default	
Device Name:	DX2300_B324	
Secure Tunnel DHCP:	Not available	
Device IP:	192.168.5.5	
Network Protocol:	UDP	

9. Click the “Unbind” button, DX-2300LN-WW will remove the registered account in DIACloud.

Description	Default
User Name	
Set up the name for the DIACloud account.	N/A
Password	
Set up the password for the account.	N/A
Verify	
Check if the username and the password are matched.	N/A
Secure Tunnel	
Select the device under the account to join in a certain secure tunnel network group. For secure tunnel related settings, go to http://www.DIACloudSolutions.com/	Default
Device Name	
Set up the name for the device	N/A
Secure Tunnel DHCP	
When secure tunneling DHCP server is available, and the IP address is allocated by the DHCP server in secure tunnel network, the IP address of this device can be found in the cloud portal.	N/A
Get IP From Cloud	
When selecting “Yes”, IP address can be obtained by the cloud. When selecting “No”, the IP address can be manually set. Page will display IP range for user reference.	Yes

Description	Default
Network protocol	
Set the network protocol of the security tunnel. Options are TCP and UDP. <ul style="list-style-type: none"> • UDP: UDP has a faster data transfer speed. If the network is not lost packet, please use this option • TCP: When the network packet loss is serious, it is recommended to select TCP. After binding the cloud account, you can still change this option, but you must disable the cloud service before changing. When the agent is turned on, the user can only select TCP. 	UDP
Cloud IP Rang	
Display the Cloud IP Range. The Cloud IP Range is depended on the secure tunnel setting. For the secure tunnel setting, please refer to 5.2.5 Tunnel Network.	N/A
Cloud Netmask	
Display the Cloud Netmask. The Cloud Netmask is depended on the secure tunnel setting. For the secure tunnel setting, please refer to 5.2.5 Tunnel Network.	N/A
Device IP	
User can assign a IP address for this device, the IP should be in the same subnet with Cloud IP.	N/A

**Notice**

- Users can log-in to <http://www.DIACloudSolutions.com/> and register for a DIACloud account.
- In rare case, you can't access the web because the computer did not refresh the IP and DNS after the activation, please re-plug the cable to resolve the issue.

3.5.2 Proxy Setting

If the user's networking environment requires outbound network connections to go through a HTTP or HTTPS proxy.

☰ CLOUD SERVICE > Proxy Setting

Proxy Setting

HTTP Proxy

Proxy Addr

Proxy Port

Proxy Username

Proxy Password

Description	Default
HTTP Proxy	
Enable or disable the http proxy	Disable
Proxy Addr	
Set up the domain/IP of the proxy server	N/A
Proxy Port	
Set up the port of the proxy server	N/A
Proxy Username	
Set up the user name to login the proxy server	N/A
Proxy Password	
Set up the password to login the proxy server.	N/A
Save and Test	
Save the configuration and test to connect to the DIACloud.	N/A

3.5.3 Secure Tunnel Firewall

In this page, user can set up the firewall for the secure tunnel.

🏠 CLOUD SERVICE > Secure Tunnel Firewall

☰ Multicast Setting

Allow Multicast In Secure Tunnel

☰ Firewall Settings

Firewall Of Secure Tunnel

ID	MAC Address	Operation
----	-------------	-----------

3

🏠 CLOUD SERVICE > Secure Tunnel Firewall

☰ Add A MAC Address

MAC Address

Description	Default
Allow multicast in secure tunnel	
Set the security tunnel, whether to allow multicast transmission of the nature of the packet. Options: Allowed, not allowed	Yes
Firewall of secure tunnel	
Set up the specified MAC device will be allow or forbid to transmit the data in the secure tunnel. Options as below: <ul style="list-style-type: none"> • Disable: Disable this function. • Black List: If the network device's MAC address is blacklisted, these devices will NOT be able to transmit packets to the secure tunnel • White List: If the network device's MAC address is blacklisted, these devices will be able to transmit packets to the secure tunnel. 	Disable
Add	
Add a new MAC into the list.	N/A

3.5.4 Cloud Log

Any information about cloud event can be exported from this function

🏠 CLOUD SERVICE > Cloud Log

☰ Cloud Log Level

Cloud Log Level

Error ▼

Save

Cloud log level will take effect when you restart the relative module.

☰ Download Cloud Log

Select The Module:

Uploader ▼

Download

Description	Default
Cloud Log Level	
<p>You can set different levels of log messages and saved to export to the engineering staff to view. Options as below (Level from low to high):</p> <ul style="list-style-type: none"> • Trace: The TRACE Level designates finer-grained informational events than the DEBUG • Debug: Fine-grained informational events that are most useful to debug an application • Info: The INFO level designates informational messages that highlight the progress of the application at coarse-grained level. • Warm: The WARN level designates potentially harmful situations. • Error: The ERROR level designates error events that might still allow the application to continue running. • Fatal: The FATAL level designates very severe error events that will presumably lead the application to abort. 	<p>Error</p>
Select Log Level	
<p>Specify to download the cloud service module log. Options as below:</p> <ul style="list-style-type: none"> • Uploader: Data upload module • Secure Tunnel: Secure Tunnel module • Binding: Account binding module 	<p>Uploader</p>

3.6 SD Card Quick Configuration



DX-2300LN provides the multiple configurations via SD Card quickly.

- Upgrade the device firmware
- Import the device configuration
- Active the device with the DIACloud account.

The SD Card quick configurations will triggers by the following file is created in the SD card after the DX-2300LN reboots:

- The upgrade-package file 'DX2300_UpgradeImage_NorFlash_XXXX_XXXX.bin'
- The device configuration files 'backup.cfg'. (Please refer 3.4.8 Backup & Restore)
- The cloud configuration file 'Provision.bin' (Please refer to the following steps).

1. Go to the DIACloud platform (DIACloudSolutions.com).
2. Log in the DIACloud webpage and click "SECURE TUNNELS"
3. Click to select the Network which you'd like to use and then click the  to see and check the details.
4. Click the  to download the generated Provision.bin to the local computer.



5. Copy Provision.bin file to SD card.

Power off the device and then insert the SD card into the device (SD card slot below the SIM card slot, on the right side of the device). Turn on the device and it will automatically bind. Check the SD card status indicator to see if the binding is successful.

The following beep codes are for SD Card Quick Configurations, its definition that the various combinations of the configuration file exist on SD card. (✘ – fail, √ - success or not this operation)

Beep Code	Upgrade.bin	backup.cfg	Provision.bin
1 long	✘	√	√
1 long, 1 short	√	✘	√

Beep Code	Upgrade.bin	backup.cfg	Provision.bin
1 long, 2 short	x	x	√
1 long, 3 short	√	√	x
1 long, 4 short	x	√	x
1 long, 5 short	√	x	x
1 long, 6 short	x	x	x
None	√	√	√

**Notice**

- Name rule for BIN file: Provision.bin
- Please do not change the file name of firmware upgrade-package.
- Please do not create the two different upgrade-package file in SD Card. In order to avoid the upgrading process fails.
- At least a 10-minute interval of separation between the two SD Card Quick Configuration

MEMO


Chapter 4 DIACom

Table of Contents

4.1	Introduction to DIACom	4-2
4.1.1	Select a Suitable Firmware Version	4-2
4.1.2	DIACom Installation.....	4-3
4.1.3	DIACloud Account Registration	4-3
4.1.4	Bind DIACloud Account.....	4-5
4.2	DIACom Operation	4-6
4.2.1	Setup a Secure Tunnel	4-6
4.2.2	Create a Virtual Serial-Port	4-10
4.2.3	Remote Control and Monitoring via DIACom	4-12
4.2.3.1	Via a LAN Port	4-12
4.2.3.2	Via a RS232/RS485 Port	4-12
4.2.4	Automation Startup	4-14

4.1 Introduction to DIACom

DIACom allows you to create a secure tunnel between your PC and router, making it possible for your PC to communicate remotely with the devices connected to the router. Thus engineers can control, monitor, operate, program and diagnose the device remotely whenever there is internet connectivity.



! Notice

- DIACloud provides you with cloud services, including the connected device management, secure tunnel network creation, data upload/download, and directional transmission.
- If you need to configure or monitor your controller, you will need to install programmable logic controller software, for example WPLSoft/ISPSoft for Delta PLC.

4.1.1 Select a Suitable Firmware Version

Find a suitable DIACom firmware version according to the following table below for your router.

Corresponding Table:

Device Model	Firmware Version
DX-2100	V1.3.3.0 or above
DX-2300	V1.3.3.0 or above

! Notice

If the device firmware is lower than 1.3.3.0, please use DIACom 1.2.8.0 or lower.

4.1.2 DIACom Installation


Obtain the DIACom firmware package from the official website or from our sales representative. Administrator privileges are required to run and install the package. Uninstall older versions of DIACom before downloading new DIACom firmware package.

 **Notice**

DIACom supports Windows XP, Windows 7 (32-bit and 64-bit) and Windows 8 (32-bit and 64-bit).

4.1.3 DIACloud Account Registration

1. Before registration, you should have a valid email account. (DIACloud uses your email address as your account.)
2. Open the DIACloud web page (<http://www.DIACloudSolutions.com>). The system will redirect you to the registration page:



 **Notice**

Click  at the upper right corner to change the interface language to English.

3. Input your email address, password and other relevant information on the registration page. Select "I Agree" and click "CREATE AN ACCOUNT".

DIA Cloud

Email *

Password *

Confirm Password *

Person Enterprise

Name *

Country


Verification Code * 6E2I6

I Agree **AGREEMENT**


CREATE AN ACCOUNT

Already have an account? **LOGIN**

4. After clicking “CREATE AN ACCOUNT”, a congratulation page will be prompted and an activation email will be sent to the email address you have used as your DIACloud account.



5. You will find an activation email sent from no-reply@diacloudsolutions.com in your email box. Open the email, click “here” link in the email and complete DIACloud account activation operation. And you will be redirected to the DIACloud login page. Input your account and password to log in to the DIACloud.



4.1.4 Bind DIACloud Account

Follow the steps blow to bind your DIACloud Account.

1. Local Network Setups: Please refer to Chapter 2.1 to 2.1.3 Web-based GUI Configuration for more information.
2. Bind DIACloud Account: Please refer to Chapter 3.5 Cloud Service for more information.



Notice

- **Secure Tunnel:** Secure tunnel is a virtual network. Users can set up several groups of secure tunnel for easier device management.
- **Device Name:** the serial number + “_” + “Mac address” of the device is the device name by default.
- **Get IP From Cloud:**
 - When selecting “Yes”: The system will assign an IP address for the device according to the Secure Tunnel settings and the availability of the IP addresses. Take note of the assigned IP address, it will be used when logging to the DIACloud.
 - When selecting “No”: The IP address can be manually set.

Secure Tunnel DHCP:	Available
Get IP From Cloud	<input type="button" value="No"/>
Cloud IP Range:	192.168.200.100 - 192.168.200.200
Cloud Netmask:	255.255.255.0
Device IP:	<input type="text"/>
(Device IP should be in the same subnet with cloud IP)	


The IP address of the DX-2300 Series and the WAN of your connected PC should be in different network segments.

4.2 DIACom Operation


4.2.1 Setup a Secure Tunnel

Make sure there is internet connectivity, before creating a secure tunnel between your local PC and router via the DIACom. Http Proxy and Port Agent are configurable in DIACom network setting function, you can set it to avoid the possible limitation.


1. Run DIACom and log in with your router's cloud account.



2. Click  to go into network setting page if need be.



- **Http proxy:** Please fill in the proxy server address, port, username and password if the LAN needs to set the proxy to access the Internet. Click "Save" button to enable the config.
- **Diagnose:** The user can click the Diagnostic button to test the current internet settings, whether to connect to the DIACloud server




Notice

- DIACom will automatically determine whether the port agent needs to enable.
- Make sure that the external network port 80 and port 443 are opened and can access any network domains and IP addresses

3. After the login is successful, the software displays the security tunnel page. The security tunnel list is displayed on the left side of the page, and the network information of the security tunnel and the device list are displayed on the right. Users can choose to use DHCP or manually set the cloud IP address

- **DHCP:** Obtain an IP address from Cloud automatically when Cloud DHCP function is available.
- **Static:** Manually set the IP address, the IP should be in the same subnet with DX device




Notice

If it is found that the static IP address is configured from DIACom, the IP address of the local IP address in the bottom right corner will be different from the original setting. Please change according to the following settings.

1. Go to Network and Sharing Center and click on the DIACom Ethernet Adapter for your network connection.



2. Right-click, then click Properties.
3. Click the Networking tab. Under This connection uses the following items, click either Internet Protocol Version 4 (TCP/IPv4) .




4. Go to Network and Sharing Center and click on the DIACom Ethernet Adapter for your network connection.



5. Right-click, then click Properties.

- Click the Networking tab. Under This connection uses the following items, click either Internet Protocol Version 4 (TCP/IPv4)



- Set the IP address of the local computer manually. However, you'll need to make sure there are no IP conflicts.

- After the configuration is complete, click the Create Tunnel button to establish a connection with the specified tunnel.
- The following information is displayed: tunnel connection status, local delay to the DIACloud cloud server, and the IP address used by the local virtual network adapter.

Status	Name	SN	Latency	IP Address	Operation
Online	DX2100_958B	DX21000518050274	157 ms	192.168.10.10	
Online	DX2300_358B	DX23000316180001	20 ms	192.168.10.20	
Online	DX2100_E98B	DX21000216140003	90 ms	192.168.10.30	

Secure tunnel is set up. 153 ms Local IP Address 192.168.10.2

- After successful connection with the cloud, the local computer will be able to use debugging tools or monitoring software to debug, monitor, and program the remote network interface devices. In addition, you can remotely configure the router's router page (click the device in the device list Of the IP address) of the router for remote configuration.


Notice

- You can create different groups of secure tunnels, divide different devices into groups according to their needs, and implement group management devices
- To avoid the virtual network card IP network segment and the local computer network card of the actual network to avoid the same network conflict
- After the secure tunnel is successfully connected, you must first disconnect the current connection to select another security tunnel,

4.2.2 Create a Virtual Serial-Port

To debug a remote serial device,

- Click the icon  at the back of the corresponding remote device to enter the Create Virtual Serial Interface



DIACom Secure Tunnel

Local IP address DHCP 192.168.10.100 - 192.168.10.200

Static 192 - 168 - 10 - 2 / 255 - 255 - 255 - 0


Status	Name	SN	Latency	IP Address	Operation
Online	DX2100_958B	DX21000518050274	157 ms	192.168.10.10	
Online	DX2300_358B	DX23000316180001	20 ms	192.168.10.20	
Online	DX2100_E98B	DX21000216140003	90 ms	192.168.10.30	

Secure tunnel is set up. 153 ms Local IP Address 192.168.10.2

- Click on the “Create” button to create a virtual COM port on the local PC, related to the RS-232 or RS-485 port on the remote devices. If the RS-232 or RS-485 port is not working with transparent mode, the corresponding “Create” button would be unavailable.

Notice

Support RS-232 and RS-485 working with transparent mode at the same time.



3 After create successfully, the local PC can perform commissioning, programming and monitoring to the remote devices with debugging tools or monitoring software.

Description	Default
PPI	
<p>Specially optimize uploading and downloading action PPI for Siemens S7-200 series.</p> <p> Notice</p> <p>Please leave unchecked for devices not included in Siemens S7-200 series to avoid failed upload/ download error.</p>	Unchecked
Auto Baudrate	
<p>Enable or disable Auto Baudrate function.</p> <ul style="list-style-type: none"> ● Checked: Perform Auto Baudrate detection. ● Unchecked: Close Auto Baudrate detection. <p> Notice</p> <p>We suggest to turn off this function if you're using Gitzo's or Mitsubishi's PLC devices.</p>	Unchecked

! Notice

- If the device's RS-232 / RS-485 is not operating in Transparent mode, the corresponding button is grayed out.
- DIACom will prompt an error message if the FW version of DX is under V1.3.3.

Error [X]

 Can't get device COM Port setting.
For device firmware under 1.3.3,
please go on to create virtual COM port.

4.2.3 Remote Control and Monitoring via DIACom

4.2.3.1 Via a LAN Port

If your router is connected to remote devices via a LAN port, you can use the configuring/monitoring software on your local computer to configure and monitor after opening a virtual tunnel. Some program would require the IP addresses of your remote device. Simply input the required information in the configuring/monitoring software and then you can configure and monitor the connected device remotely.

4.2.3.2 Via a RS232/RS485 Port


After opening a virtual tunnel, you will need to follow the setups below before using WPLSoft or other configuring/monitoring software on your local computer to configure and monitor the connected device remotely.

1. Click IP address in the DIACom device list or open a browser and input the IP address of the router which is connected to your remote device on the search bar and then log in.
2. Go to the System setup page, select the setup option RS232 or RS485 and input the required information to set up. Make sure the parameters are consistent with your remote device.

- Working Mode : Transparent mode
- Parameters of COM (Baud Rate, Data Bits, Stop Bits, Parity Bits, Flow Control)

Working Mode	<input type="text" value="Transparent mode"/>
Baud Rate	<input type="text" value="9600"/>
Data Bits	<input type="text" value="8"/>
Stop Bits	<input type="text" value="1"/>
Parity Bits	<input type="text" value="None"/>


3. Go back to the DIACom and click  to create a virtual tunnel. Once the creation is done, the virtual serial-port number will show up on the same page. Users can use it to configure and monitor the connected device remotely. Click "Delete" to delete the virtual serial-port.



! Notice

If the PLC is Siemens S7-200, you can select the “PPI” in the DIACom to support PPI protocol.


4. Open the WPLSoft to check if the COM parameters are consistent with the settings on your router. When these parameters are consistent, you can use the WPLSoft to configure/monitor your device remotely.



4.2.4 Automation Startup

Users can set Automation Startup for DIACOM, The setting steps see blow.

1. Login to DIACom.
2. Click on the icon button  in the upper right corner of the windows, and select "Settings".
3. Boot automatically log in the required configuration is as follows. Users can set according to your needs. If you only need DIACom to connect the security tunnel automatically, the device list, RS-485 and RS-232 do not need to be set.



The screenshot shows a 'Setting' window with the following configuration:

- Secure Tunnel: default
- DHCP IP Range: 192.168.200.100 - 192.168.200.200
- Local IP address: DHCP Static
- IP Address: 192 - 168 - 5 - 10 / 255 - 255 - 255 - 0
- Device Name: None
- RS-485: COM6 PPI
- RS-232: COM5
- Start DIACom on windows logon
- OK button

4. Check " Start DIACom on windows logon ", and click "OK" button to save the settings.

Notice

- Login must be checked "remember password", otherwise DIACom can not be activated automatically
- Confirm that the IP / Serial Port settings do not cause conflicts

Chapter 5 DIACloud

Table of Contents

5.1	Introduction to DIACloud	5-2
5.1.1	Select a Suitable Firmware Version	5-2
5.2	Instructions for DIACloud.....	5-2
5.2.1	Register and Login	5-2
5.2.2	Home	5-4
5.2.3	Devices	5-6
5.2.4	Alarm.....	5-16
5.2.5	Secure Tunnels	5-16
5.2.6	Sub Users	5-18
5.2.7	Logs	5-21
5.2.8	Orders.....	5-22
5.2.9	Profile	5-23

5.1 Introduction to DIACloud

DIACloud Web is a web portal of DIACloud cloud platform. Users can check the status of connected industrial device through DIACloud Web, browse data that has been collected, receive warnings, notices and other messages that are sent by cloud platform, create and manage sub-account and virtual safety network and check login and interface logging, to improve the manageability of devices, optimize the device performance and efficiency, save the operation cost and enhance the service quality.

5.1.1 Select a Suitable Firmware Version


Please confirm that your Firmware version of router meets the requirements in the following table before use:

Device Model	Firmware Version
DX-2100	V1.3.0.1 or above
DX-2300	V1.0.0.1 or above

5.2 Instructions for DIACloud

5.2.1 Register and Login


1. Open the DIACloud web page (<http://www.DIACloudSolutions.com>). If you have got an account, input your account and password in the following page to log in; if you have not got an account, click "CREAT AN COUNT" to register. Then the system will redirect you to the registration page:



2. Input your email address, password and other relevant information on the registration page. Select "I Agree" and click "CREATE AN ACCOUNT". Please insure your region information is correct, otherwise it may cause problems in payment when you extend your service.


 **Notice**

Click  at the upper right corner to change the interface language to English or Chinese.



The screenshot shows the DIACloud account creation interface. It features a blue header with the 'DIACloud' logo. Below the header is a white form with several input fields: 'Email *', 'Password *', 'Confirm Password *', 'Name *', and 'Country'. There are radio buttons for 'Person' and 'Enterprise', with 'Enterprise' selected. A 'Verification Code *' field is present with a '61MIU' code displayed next to it. At the bottom, there is a checkbox for 'I Agree' and a red 'AGREEMENT' link. A grey 'CREATE AN ACCOUNT' button is at the very bottom.

3. After clicking "CREATE AN ACCOUNT", a congratulation page will be prompted and an activation email will be sent to the email address you have used as your DIACloud account.



4. You will find an activation email sent from no-reply@DIACloudSolutions.com in your email box. Open the email, click the link in the email and complete DIACloud account activation operation. And you will be redirected to the DIACloud login page. Input your account and password to log in to the DIACloud.

Activate your account on DIACloud

发件人: DIACloud<no-reply@diacLOUDSOLUTIONS.COM>

收件人: 我<steven8160@163.com>

时间: 2016年05月11日 11:07 (星期三)

Dear User,

Please complete your registration by following the link below:

<http://www.diacLOUDSOLUTIONS.COM/#/activate?n=steven8160%40163.com&t=fM1xduuNyNZSo4NNyVQCUX5ACGrO5II>

Please activate your account within 48 hours, otherwise you need to re-create your account.

If you did not register recently, or believe you have received this email in error. Please disregard this message.

请点击下面的链接完成注册:

<http://www.diacLOUDSOLUTIONS.COM/#/activate?n=steven8160%40163.com&t=fM1xduuNyNZSo4NNyVQCUX5ACGrO5II>

请在48小时内激活您的账号, 否则您需要重新注册。

如果该账号不是您本人注册的, 请忽略本邮件。


Thanks!

The DIACloud Team

5. Open the DIACloud web page (<http://www.DIACLOUDSOLUTIONS.COM>). Log in using your account that you have registered.

5.2.2 Home

The Home Page will show up after login.



Item	Description
Menu	User can switch to corresponding function through menu on the left.
Devices Total	The number of total devices.
Devices is Online	The number of total online devices.
Alarms in 24 Hours	The number of alarms in Recently 24 hours.
Secure Tunnel is Usable	It will show the number of Secure Tunnel groups under the account.
	Switch between Chinese and English
	Show the service package you selected, users can add package to shopping cart through Devices function and Profile function.
	Show the alarm message(s) in latest 7 days
	Show the profile or logout

Online payment process as below:

- After click , it will show the detail information in shopping cart.

Shopping Cart					
#	Package Name	Unit Price	Number	Price	Operation
1	DX-Service-T1GB-WW (SN : DX21000216140002) Data traffic fee of 1-year package for 1G bytes extra traffics per month between device and DIACloud	\$ 0.01	4	\$ 0.04	
2	DX-Service-S1MB-WW Cloud Storage fee of 5-years package for 200MB storage space in one account	\$ 0.01	1	\$ 0.01	
Total 2 item(s) in Cart				Total Price	\$ 0.05 CHECKOUT

- Click [CHECKOUT](#) to generate an order. DIACloud provides the follow types of invoices.
 - No need For Invoice
 - Electric Invoice
 - Paper Invoice

Confirm Order

Order Detail

DX-Service-T1GB-CN (SN: DXR02010F270086)	¥200	x1
--	------	----

Total Price: **¥ 200**

Invoice

No need for Invoice
 Electric Invoice
 Paper Invoice

Invoice Title (The terms of your company) *

Email *

[BACK TO CART](#)
 [CONFIRM ORDER](#)

3. Click [CONFIRM ORDER](#), we accept PayPal payments and process credit cards on your order forms.

Payment Method

Total to pay now **\$ 0.05**



[PAY NOW](#)


5.2.3 Devices

It will switch to page of device list after clicking “Devices” in navigation bar.

#	Status ↓	Device Name	SN	Device Type	Storage Usage	Data Usage	Created	Operation
1	online	DX2100_B0B4	DXR02010F210059	DX2100	0.00 MB	0.00 MB	2016-10-17 09:09	...
2	offline	DX2100_F0D3	DXR02010F270038	DX2100	0.00 MB	0.00 MB	2016-07-22 12:36	...
3	offline	DX2300_894D	DX23000216260012	DX2300	0.00 MB	0.00 MB	2016-07-28 22:31	...
4	offline	DX2300_89AB	DX23000216260059	DX2300	0.00 MB	0.00 MB	2016-09-08 13:34	...
5	offline	DX2300_894B	DX23000216260011	DX2300	0.00 MB	0.00 MB	2016-11-14 10:54	...
6	offline	seyl	DX23000216260048	DX2300	0.00 MB	0.01 MB	2016-11-18 15:16	...
Total 6 Device(s)								

Item	Description
 Search	You can filter the device base on you input the key word of the device name.
 All	Filter base on tunnel group, show all devices or only show the devices under user specified tunnel group.
Devices List	Show the list of device.The information includes device's name, device's SN, device's type, storage usage, data usage and the time of binding device. <ul style="list-style-type: none"> Green represents that the device is online Gray represents the device is offline.
	<ul style="list-style-type: none">  : Represents that all device is displayed currently, and you can switch to on-line device list after clicking this icon.  : Represents that on-line device is displayed currently, and you can switch to list of on-line device after clicking this icon.
	Show relevant position information of the device.
	Refresh pages
...	Show detail information of the device

-  : It will show relevant position information of the device after you click "", which is shown as follows:



It will show the device name and SN of the device after clicking position icon in the map. When a large number of devices bound to the user's account, it will switch to other corresponding devices when user clicks blue arrows at the edge of the map.

- ... : More detail information about the device will be shown after clicking ... under the "Operation" on the right side of the device list:

1. **OVERVIEW:** The page will show the basic information of the device and the latest alarm message.




5

Item	Description
Operation zone of device	<p>It represents that device is online if background color is blue, and device is offline if shows gray.</p> <ul style="list-style-type: none"> • DX2100_B0B4 ▼ : Show device names; it can switch device after clicking the drop down arrow. •  : Realize refresh of device data on operation page. •  : Close the operation page.
Page switching	<p>Operation is divided into 4 pages:</p> <ul style="list-style-type: none"> • Overview • Registers • Package • More <p>Different buttons are used to switch different pagers.</p>
Basic information zone	<p>Basic information is shown in Overview page.</p> <ul style="list-style-type: none"> • IP Address: IP address of a device; • Tunnel Network: it means virtual network that has been bound to device; • Boot Time: it means the boot time of device; • RS232 Mode: work modes of RS232, including transparent transmission mode and slave station mode; • RS485 Mode: work modes of RS 485, including transparent transmission mode, slave station mode and master station mode;

	<ul style="list-style-type: none"> • Modbus TCP: work modes of Modbus TCP, including Modbus TCP Server, Modbus TCP Client and Closed • RSSI: it means signal strength of device which contains 5 bars; the larger the number of green bars is, the stronger the signal strength is;
Latest Alarms	<p>The latest five Alarm of the current device. “” represents the state that the email has been sent;</p> <ul style="list-style-type: none"> • Green represents that the email has been sent successfully • Red represents failure of sending.

2. **REGISTER:** The page will show and manage register value that uploaded from DX devices.




5

Item	Description
 Search	The filtering function displays a list of keywords that match specific registers.
	Click  and add the corresponding register and register value, then click “SAVE” button. DIACloud server will send the corresponding data to the device.
< 1/205 >	“<” Pervious page · “>” Next page · “1/205” show the current page of register table and the total amount of register table page.

Register Table	Show the register table, displaying a maximum of 10 registers per page.
Register Name	Show the register name, when you do not configure an alias in the register, the register number is displayed.
Register Value	Show the current register value and data transfer time.
⋮	You can view the current register of historical data or delete the current register; it can also be configuring registers. P.S. If this register is not set to remember history (device configuration page), the menu does not appear [History] after clicking ⋮ icon.

The History and Config options will be shown after clicking ⋮



5

Item	Description
History	It represents trend chart of historical data
Delete	User can delete all the data of a target register.
Config	User can customize name of register and content returned.

- **History** : The following figure will be shown after clicking “History”:



Item	Description
Date Start	Set the Start Date and query the historical data for a specific time.
Date End	Set the End Date and query the historical data for a specific time.
Register Value History Diagram	The latest trend chart of value of register;
Time Axis	Users can change time scope of historical data by sliding "1".
	Export the data to XLS.file.

- **Config** : The following information will be shown after clicking "Config"

The "Register Configuration" dialog box contains the following fields and content:

- Register Address**: Input field with value "2050".
- length**: Dropdown menu with "Word" selected.
- Alias Name**: Input field with value "\$2050".
- JavaScript Template**: A code editor containing the following code:


```
function(val) {
    return val;
}
```
- SAVE**: A button at the bottom right.

Item	Description									
Length	<p>Length can be set to Word, DWord and Float.</p> <ul style="list-style-type: none"> DWord: DWord needs to use two DX internal registers. For example: \$2050 and \$2051 are set to DWord and combined as one. \$2050 will be LOW Byte and \$2051 will be HIGH Byte. <div style="border: 1px solid black; padding: 5px; margin: 5px 0;"> <table style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 30%;">\$2050</td> <td style="width: 30%;">786447 </td> <td style="width: 40%; text-align: right;">2017-08-14 11:33 </td> </tr> <tr> <td colspan="3" style="border-top: 1px solid gray; height: 1px;"></td> </tr> <tr> <td>\$2052</td> <td>233 </td> <td style="text-align: right;">2017-08-07 09:06 </td> </tr> </table> </div> <ul style="list-style-type: none"> Float: Float needs to use two DX internal registers. For example: \$2050 and \$2051 are set to DWord and combined as one. \$2050 will be LOW Byte and \$2051 will be HIGH Byte. 	\$2050	786447	2017-08-14 11:33				\$2052	233	2017-08-07 09:06
\$2050	786447	2017-08-14 11:33								
\$2052	233	2017-08-07 09:06								
Alias Name	Users can set the display name of the register in "Alias Name"									
function(val)	function(val) is used for converting register values and similar to the grammar of function-supported JavaScript.									

There are two examples for “function (val)”.

- Example 1 :** If you want to show the wind speed as 10m/s. (Data +unit, such as: speed 10m/s).
Input the code: `return val+"m/s"` in `function (val){...}` as the following picture and save the configuration.

Register Configuration
✕

Register Address
2050

length
Word ▼


Alias Name *
wind speed

function(val) {
JavaScript Template
return val+"m/s";
}


SAVE

- **Example 2:** If you want to convert the register value to the text such as the register value of 1 showing the text as 'NO'; register value of 2 showing the text as 'OFF'

Input the code in function (val) {...} as the following picture and Click "Save" button.




3. **SERVICES:** This page shows the Device Data Usage, Device Storage Usage and Account Storage Usage for users.



Item	Description
Data	<ul style="list-style-type: none"> • Device Data Usage: Show device traffic usage till now and total capacity. • Account Traffic Usage: <ol style="list-style-type: none"> 1. Account traffic is the total amount of traffic showing additional purchases. 2. Account traffic can be shared with all devices under your account. 3. Before the device traffic is exhausted cloud traffic, the account traffic will not be used. • BUY: User can purchase more traffic package for this account if need. After successful payment, the moment is ready for use. • HISTORY: Show the Data Usage History in past 12 months.
Storage	<ul style="list-style-type: none"> • Device Storage Usage: Show device storage usage till now and total capacity. • Account Storage Usage: <ol style="list-style-type: none"> 1. Account storage is the total amount of traffic showing additional purchases. 2. Account storage can be shared with all devices under your account. 3. Before the device storage is exhausted storage space, the account storage will not be used. • BUY: User can purchase more traffic package for this account if need. After successful payment, the moment is ready for use.

- After Click the **BUY** in Data field, it will show the traffic package select page. User can add a package to cart or checkout directly.



Add To Cart [X]


DX-Service-T1GB-WW
Data traffic fee of 1-year package for 12G bytes extra traffics one year between device and DIACloud

Unit Price: \$ 0.01
Expired: 2018-08-14

Package Name: DX-Service-T1GB-WW
Number: 1

[ADD TO CART] [CHECKOUT]

- After Click the **HISTORY**, it will show the Data Usage History in past 12 months.



- After Click the **BUY** in Storage field, it will show the storage package select page. User can add a package to cart or checkout directly.

Add To Cart

DX-Service-S1MB-WW
 Cloud Storage fee of 5-years package for 200MB storage space in one account

Unit Price: \$ 0.01
 Expired: 2022-08-13

Package-Name: DX-Service-S1MB-WW
 Number: 1

ADD TO CART **CHECKOUT**

5

4. **MORE:** This page will show the Serial Number, Software Version, Hardware Version, and IMEI for users.

DX2100_B0B4

OVERVIEW REGISTERS SERVICES **MORE**

Serial Number	DXR02010F210059
Software Version	DX2100WW-1.3.3.1-2016-11-14
Hardware Version	DX2100 v3
IMSI	466974400866952

DELETE

Item	Description
Serial Number	Serial number of device
Software Version	Version information of software
Hardware Version	Version information of hardware
IMSI	International Mobile Subscriber Identification Number.
	Delete binding relationship between devices and the account. Devices need to be un-bund after clicking this button, and users can recover the device by rebinding.


5.2.4 Alarm

Click the Alarm in the left menu. The warning information in the latest 7 days will be shown in this page. The warning information includes name and serial number of device, content of warning, status of email that is being sent (green“” represents that the email has been sent successfully, and red represents fail.), time of warning and content record of warning.

#	Device Name	Alarm Message	Status	Created
1	VFDControl DXR02010F210059	!!!!!!WARNING!!!!!! VFD Status : Emergency Stopped Time : 2016/03 /1418:18:28 MS300 has been stopped, please contact the relevant member!!!		2016-03-14 18:18:31
2	VFDControl DXR02010F210059	!!!!!!WARNING!!!!!! VFD Status : Emergency Stopped Time : 2016/03 /1418:16:25 MS300 has been stopped, please contact the relevant member!!!		2016-03-14 18:16:41
3	HMI DXR02010F210039	0 1 2016/03/14 18:15:42		2016-03-14 18:16:15
4	VFDControl DXR02010F210059	!!!!!!WARNING!!!!!! VFD Status : Emergency Stopped Time : 2016/03 /0913:28:10 MS300 has been stopped, please contact the relevant member!!!		2016-03-09 13:28:12
5	VFDControl DXR02010F210059	!!!!!!WARNING!!!!!! VFD Status : Emergency Stopped Time : 2016/03 /0913:27:57 MS300 has been stopped, please contact the relevant member!!!		2016-03-09 13:28:01
6	VFDControl DXR02010F210059	!!!!!!WARNING!!!!!! VFD Status : Emergency Stopped Time : 2016/03 /0913:26:46 MS300 has been stopped, please contact the relevant member!!!		2016-03-09 13:26:50
7	VFDControl DXR02010F210059	!!!!!!WARNING!!!!!! VFD Status : Emergency Stopped Time : 2016/03 /0913:24:22 MS300 has been stopped, please contact the relevant member!!!		2016-03-09 13:24:32
8	HMI DXR02010F210039	0 1 2016/03/09 13:20:16		2016-03-09 13:20:47
9	VFDControl DXR02010F210059	!!!!!!WARNING!!!!!! VFD Status : Emergency Stopped Time : 2016/03 /0819:01:37 MS300 has been stopped, please contact the relevant member!!!		2016-03-08 19:01:42

5.2.5 Secure Tunnels

Secure Tunnel is an important concept in DIACloud. Its objective is to realize virtual Switch across Internet; when device is bound to this network, it will be equivalent to add devices with one LAN port; when PC operates DIACom and creates a virtual network, PC and the device will be under the same switch at this time. It is shown as follows




Users can manager the tunnel network in this page. Interface is shown as follows:

#	Network Name ↑	DHCP	DHCP IP Range	Status	Operation
1	DeltaNetwork	Enable	192.168.200.100 192.168.200.200	Normal	...
2	HM2016	Enable	192.168.199.100 192.168.199.200	Normal	...

Total 2 tunnel network(s)

tem	Description
🔍 Search	Search the existed tunnel network.
Tunnel network List	List all tunnel network under this account.
+	Add a new tunnel network.
🔄	Refresh the tunnel network list.
...	Edit the tunnel network.



5

Item	Description
Tunnel Network Information	The detail information of tunnel network: <ul style="list-style-type: none"> • Network Name: User can enter a name of tunnel network. • DHCP Option: Automatic IP Address Assignment by DIACloud. • DHCP IP Start: it represents the beginning IP in automatic IP distribution address pool of DIACloud • DHCP IP End: it represents the ending IP in automatic IP distribution address pool of DIACloud.
	If the DHCP of this tunnel network is enabled, click  will export configurations include DIACloud Servier /account /Tunnel networks info to a file (default file name Provision_vlnname_date_time.bin). Note: Detail configuration, please refer to 3.2 SD Card Quick Installation .
	Delete the current tunnel network
	Close the current operation window.
	Save the configuration of tunnel network

5.2.6 Sub Users


All accounts that are registered through register page of DIACloud (<http://www.DIACloudSolutions.com/#/signup>) are main accounts. Every main account can create sub-accounts, and users can realize power separation and grouping management of device by conducting authorization for virtual network and DIACom by sub-account. Use can conduct addition and operation for sub-account through the “Sub Users” page.

#	Account ↑	Login to EthDirect	Status	Created	Operation
1	3208467055@qq.com	Disabled	Activated	2016-02-24 20:02:29	...
2	444386414@qq.com	Enabled	Activated	2015-10-27 22:04:34	...
3	shinewaker@sina.cn	Enabled	Activated	2016-02-25 17:06:26	...
4	test_lot@126.com	Enabled	Activated	2016-02-29 17:35:54	...
Total 4 user(s)					

Item	Description
 Search	Search the sub users.
Sub Users List	Show the list of all sub users in main account.
	Add a sub user.
	Refresh the list of sub users.
...	Modify the access control of the tunnel network.


5

- ... : User can modify the access control of the tunnel network.



Item	Description
Sub Users Information	<ul style="list-style-type: none"> • Edit register: Allow the Sub User to modify register • Login to DIACom: Allow the sub user to access the DIACom if the option is enabled. • Tunnel Network: Allow the sub user to access the Tunnel Network if the option of Tunnel Network is checked.
	Delete a sub user.
	Close the current operation window.

- **+** : User can add sub users after clicking the “+” on the page, and the following interface will be shown after clicking the “+” in the page:



Account:
diac0@163.com

Edit register

Login to DIACom

Secure Tunnels

Project1

Test_Hangzhou

default1

default

SAVE

1. Fill in corresponding account information and conduct authorization for it.
2. The system will send an activation email which is attached with random login password to email box of sub user. The account status is “Un-activated” now.
3. Go to the mailbox, click the hyperlink to complete account activation operation, then sub user can login DIACloud with new account.
4. The page will link to the following page after clicking the activation link in the email:

Activate your account on DIACloud Inbox x

DIACloud <no-reply@diacLOUDSOLUTIONS.COM>
to me ▾

3:40 PM (0 minutes ago) ☆



Dear User,

Please complete your registration by following the link below:

<http://www.diacLOUDSOLUTIONS.COM/#/activate?n=ww7843673%40gmail.com&t=l8SmPDnpyl24XV6llncjZJ5hbGSSUAE>

Please activate your account within 48 hours, otherwise you need to re-create your account.

If you did not register recently, or believe you have received this email in error. Please disregard this message.

请点击下面的链接完成注册:

<http://www.diacLOUDSOLUTIONS.COM/#/activate?n=ww7843673%40gmail.com&t=l8SmPDnpyl24XV6llncjZJ5hbGSSUAE>

请在48小时内激活您的账号，否则您需要重新注册。

如果该账号不是您本人注册的，请忽略本邮件。

Thanks!

The DIACloud Team

- When user login to DIACloud with main account and the sub user that we created has been activated.

5.2.7 Logs

This page will show the web operation information of some users. It includes: login IP, setup of register, API interface call of DIACloud and other information.



#	User Name	Log Content	Created
1	13616061750@163.com	push reg , cmd = 21300,1,2049,556	2016-04-01 11:12:41
2	13616061750@163.com	Login from 211.97.130.218	2016-04-01 11:11:36
3	13616061750@163.com	Login from 218.66.157.46	2016-04-01 10:45:41
4	13616061750@163.com	Login from 211.97.130.218	2016-04-01 10:43:23
5	13616061750@163.com	Edit tunnel network, id= 1247, name = test02, dhcp = 1	2016-04-01 10:38:20
6	13616061750@163.com	Logout	2016-04-01 10:37:55
7	13616061750@163.com	Login from 218.66.157.46	2016-04-01 10:37:54
8	13616061750@163.com	Login failed. username=13616061750@163.com from ip=218.66.157.46	2016-04-01 10:37:48
9	13616061750@163.com	Login failed. username=13616061750@163.com from ip=218.66.157.46	2016-04-01 10:37:41
10	13616061750@163.com	Login failed. username=13616061750@163.com from ip=218.66.157.46	2016-04-01 10:37:35

10 ▾ 1 - 10 / 1134 < > >>

5.2.8 Orders

In this page, users can check all orders. Continue to pay for the unpaid orders or cancel the unpaid orders.

#	Order NO.	Amount	Created	Status	Operation
1	120160506042313747581	\$ 100	2016-05-06 16:23:13	Wait for Payment Order Detail	PAY Cancel
2	120160506042243779488	\$ 99.99	2016-05-06 16:22:43	Wait for Payment Order Detail	PAY Cancel
3	120160506110245733298	\$ 99.99	2016-05-06 11:02:45	Wait for Payment Order Detail	PAY Cancel
4	120160505060220111921	\$ 0.01	2016-05-05 18:02:20	Finished Order Detail	
5	120160505052319041416	\$ 0.01	2016-05-05 17:23:19	Finished Order Detail	
6	120160505052149784903	\$ 0.01	2016-05-05 17:21:49	Finished Order Detail	
7	120160505052038875275	\$ 0.01	2016-05-05 17:20:39	Finished Order Detail	
8	120160505051413353285	\$ 0.01	2016-05-05 17:14:13	Finished Order Detail	
9	120160505051019658664	\$ 0.01	2016-05-05 17:10:20	Wait for Payment Order Detail	PAY Cancel
10	120160505050752270363	\$ 0.01	2016-05-05 17:07:52	Wait for Payment Order Detail	PAY Cancel

5

Item	Description
Order Detail	View the order detail information
PAY	Pay for the unpaid order
Cancel	Cancel the order, order will remove from the list.

- Order detail

Order Detail			
#	Package Name	Unit Price	Number
1	DX-Service-S1MB-WW Cloud Storage fee of 5-years package for 200MB storage space in one account	\$ 0.01	x1
			Total Price \$ 0.01

- Payment Method: Currently, we only support PayPal payment for the world wide user.

Payment Method


Total to pay now **\$ 99.99**



PAY NOW


5.2.9 Profile

In this page, QR Code of user, Package info, password management and other information will be shown.



Item	Description
QR Code	You can get the part information of user by using DIACloud APP and scanning QR Code.
Account	The current account information.
Package info	<ul style="list-style-type: none"> Show account traffic/storage usage till now  Users can purchase more traffic/storage package for this account if need  Account traffic/storage will be shared to all devices under this account.
Change Password	<p>Change the password of DIACloud user account.</p> <p>Note: parts of old users use password in 6 digits; the new password has been increased to 8 digits to improve safety of their accounts.</p>

Change Password page as below



MEMO


Chapter 6 DIACloud APP

Table of Contents

6.1	Introduction to DIACloud APP	6-2
6.1.1	Select a Suitable Firmware Version	6-2
6.1.2	DIACloud APP Installation	6-2
6.2	DIACloud APP Function	6-2
6.2.1	DIACloud APP Login	6-2
6.2.2	Device List.....	6-4
6.2.3	Device Details	6-5
6.2.4	Registers View	6-6
6.2.5	Alarm List.....	6-7

6.1 Introduction to DIACloud APP

DIACloud APP is the client software of DIACloud cloud platform running on mobile devices. The APP supports both iOS and Android mobile system, it enables users to view the collected field data, the locations of the field devices, and the alarms/notifications pushed by the industrial IOT cloud platform, so that keep users posted anytime and anywhere, and therefore improve the manageability of devices, optimize the device performance and efficiency, save the operation cost and enhance the service quality.



6.1.1 Select a Suitable Firmware Version

The APP can support the devices below:

Device Model	Firmware Version
DX-2100	V1.3.0.1 or above
DX-2300	V1.0.0.1 or above

6.1.2 DIACloud APP Installation


The DIACloud APP is available on Google Play and Apple APP Store.

Mobile Device	OS Version
Android	4.4.0 or above
iPhone	6.2.0 or above

6.2 DIACloud APP Function

6.2.1 DIACloud APP Login


Enter the DIACloud account and password, then click the “Sign in” button to login the APP. Click the “Sign up” to register an account if you don’t have one.



Item	Description
	Scan QR code, the QR code is generated by DIACloud Web portal, which carries the user name and password information. By scanning the QR code, user won't need to input user name. By default, the APP will connect the default DIACloud server in the cloud, if the APP is to connect other servers, QR code should be scanned to provision the APP.
	DIACloud account, Email format
	The password of DIACloud account, click  to see what are you input
Auto Login	Save the password and login the APP automatically
Login	Login to App
Sign up	Create a new DIACloud account
Forget	Reset the password if you forget it.
	Switch the language.

6.2.2 Device List

Device list will be shown after logging in the APP.




Device tab and alarm tab will be shown in the APP. In the device tab, the device information will be shown, including the value of registers of the remote device. And the value of the register can be changed in the APP as well. In the alarm tab, users can read the alarm messages.

Item	Description
	Logoff or exit App
Search	Search device base on key word
All/Online	<ul style="list-style-type: none"> Click "ALL" to show all device Click "Online" only show online device. Digit at the back is the all/online device count.
Device list	Display device online/offline status, device name, device serial number. Click it will go into device detail page
	Switch to device list page
	Switch to alarm list page.

6.2.3 Device Details

Device details will be shown by selecting a device in the device list.



Item	Description
Type	Type of the device
Time	The time when the device is online.
IP	IP Address of the device
Account	The DIACloud account which activates the device.
Mode	The working mode of RS485 and RS232. <ul style="list-style-type: none"> • RS232: Transparent transmission mode or Slave mode • RS485: Transparent transmission mode /Slave mode /Master mode
Map	Showing the location of the device on the map P.S. DX-2300 Series doesn't support this function.


6.2.4 Registers View

Click [Register] on the device details page to switch to the register page

In the register page, the user can browse the collected data. The register data can be refreshed by the pull-down screen. When the number of registers is large, you can pull up the screen to display more data.



Item	Description
	Refresh the register data.
	Edit the register value.




Click “ok” button, the register value will be pushed to the device.

6.2.5 Alarm List

Alarm criteria can be set on the device configuration web page. When the alarm criteria are met, the device will send out alarm messages. User can click the “Alarm” tab to read the alarm messages. When there are new alarm messages, the number of the unread messages will be shown on the icon .

- Alarm tab will be shown by clicking icon , the alarm messages in Red are unread messages. Digit in parentheses is the number of alarm messages.
- Pull down the APP to refresh the alarm list.



MEMO