



## NRAQ.E206327 Programmable Controllers

[Page Bottom](#)

### Programmable Controllers

[See General Information for Programmable Controllers](#)

#### **DELTA ELECTRONICS INC**

E206327

31-1 SHIEN PAN RD  
KUEI SAN INDUSTRIAL ZONE  
TAOYUAN HSIEN, 333 TAIWAN

**Accessories, Communication interface:** DVP followed by CP, DT or PF, followed by 02, followed by H, maybe followed by additional suffixes or blank.

**Accessories; Temperature sensor:** DVP08TC-H, maybe followed by additional suffixes.

**Communication accessory device,** Model RTU-EN01.

**Communication interface units,** Models DNA02, COA02, DVPEN01-SL, DVPCOPM-SL, RTU-485, RTU-DNET, ENA01-MOD, ENA01-EIP, DVPPF02-SL, RTU-PD01.

Model DVS, followed by 005, 008 or 016, followed by any alphabets, numbers or blank.

Models DMV1000-80GX and keypad accessory DMV1000-KEY.

**Control modules,** DVP followed by 14, 16, 24, 30, 32, 20, 40 or 60, followed by ES, EX, SS or EC, may be followed by 2, followed by 00, 01, 10 or 11, followed by R, S or T, may be followed by additional suffixes.

DVP followed by 16, 20, 32, 40, 48, 60, 64 or 80, followed by EH, followed by 00, followed by R, T or M, may be followed by additional suffixes; DVP20PM00D, DVP20PM00M, DVP10PM00M may be followed by additional suffixes

DVP14SS11T, DVP14SS11R, DVP14SS11R2, DVP14SS11T2, DVP14SS11R, may be followed by additional suffixes.

DVP followed by 10 or 28, followed by SX or SV, followed by 11, followed by R or T; DVP followed by 12, 10 or 32, followed by SA, SC, MC or ES, may be followed by 2, followed by 11, followed by R, S, T or P, followed by additional suffixes or blank.

Models DVP12SE11R, DVP12SE11T followed by additional suffixes or blank.

Model DCH1000A.

ELC followed by PC, followed by 12, followed by N, followed by N, followed by A, followed by R; Model DVP12SA10R may be followed by additional suffixes.

DVP followed by 12, 14 or 20, followed by SS2 or SX2, followed by 11, followed by R, T or S, may be followed by additional suffix.

**Expansion I/O units,** DVP followed by 08, 14, 16, 24 or 32, followed by XM, XN or XP, may be followed by 2, followed by 00, 01 or 11, followed by R, N or T, may be followed by additional suffixes.

DVP followed by 02, 04, 06, followed by AD, DA, TC, XA or PT, followed by E2, may be followed by additional suffixes, rated 24V dc.

DVP followed by 08, 16, 32 or 48, followed by HN, HM or HP, followed by 11 or 00, followed by R, T or N, may be followed by additional suffixes; DVP followed by 01 or 02, followed by HC, followed by -H, may be followed by additional suffixes; Models DVP01PU-H, DVP06XA-H, may be followed by additional suffixes.

**Expansion modules,** DVP16SP11R, DVP16SP11T, DVP08SM11N, DVP08SN11R, DVP08SN11T, DVP08SP11R, DVP08SP11T, may be followed by additional suffixes.

DVP followed by 01, 04 or 06, followed by AD, DA, PT, PU, followed by -S; Modules DVP06XA-S, DVP02DA-S, DVP08RT-S, DVP04TC-S followed by additional suffixes or blank.

DVP followed by 06, 08, followed by SN, ST, followed by 11, followed by R, N, followed by additional suffixes or blank.

Model DVP10RC-E2 followed by additional suffixes or blank.

ELC followed by EX, followed by 08, followed by N, followed by N, followed by A, followed by N; Models DVP08SM10N, ADP485-01, DVDPNET-SL, DVP16SM11N, DVP16SP11TS, DVP16SN11T, DVP32SM11N, DVP32SN11TN, DVP02LC-SL, DVP01LC-SL. Followed by additional suffixes or blank.

DVP followed by PF or DT, followed by 01, followed by -S, followed by additional suffixes or blank.

Model DOP followed by -EX, followed by IO, followed by 28 or 14, followed by R, followed by AE; Model DOP followed by -EX, followed by LN, followed by G, H or T, followed by J, followed by 1, 2 or 4, followed by AE.

**Expansion unit**, Model DVP, followed by 04, followed by DA or AD, followed by -SL.

**Hand held programmer**, DVPHPP0, followed by additional suffixes.

**Human machine interface**, Model DOP, followed by -B, followed by -07, -08, or -10, followed by S or E, followed by 41x, 411, 415, 515 or 615, may be followed by additional suffix.

Model HMC, followed by 08, followed by -, followed by A-Z, followed by 0-9, followed by 00-99, followed by S, followed by 0-6, followed by 0-6.

Models DOP-B03 followed by E or S, followed by 210 or 211, may be followed by additional suffixes.

**Power modules**, DVPPS01, DVPPS02.

**Programmable human machine interfaces**, Model TP followed by 02, 04, 05 or 08, followed by T or G, followed by A or B, followed by S, followed by 1 or 2; Models TP04G-AL-C, TP04G-BL-C.

Models TP followed by 04, followed by P, followed by 00-99, followed by TP, EX or XA, followed by additional alphanumeric letters or blank.

DOP followed by -A or -AE, followed by 57, followed by G, C or B, followed by STD, may be followed by -W; Models DOP-AS57BSTD, DOP-A75CSTD, DOP-AE80THTD, DOP-AE80THTD0, DOP-A10THTD1, DOP-AE10THTD, DOP-AE10THTD1, DOP-A10TCTD, DOP-AS38BSTD, DOP-AS38BSTD-W, DOP-B07S200, DOP-B05S100, DOP-B05S101, DOP-B07S201, DOPB07S201A, DOP-B07S211, DOP-AS35THTD and DOP-B07S411K.

Models DOP-NP3 followed by -MQ, followed by 0 through 9, followed by 0 or 1, followed by 0 or 1, may be followed by B.

Models DOP-NP5 followed by -MQ or -SQ, followed by 0 through 9, followed by 0 or 1, followed by 0 or 1, may be followed by B.

**Programmable logic controller**, Model DVP followed by 10 through 60, followed by EC, followed by 00, followed by R or T, may be followed by additional suffix.

**Pressure sensor**, Model DPA01 or DPA10 may be followed by additional suffix.

**Accessories**: DPA-CBL, QPS-CBL.

**Listed Accessories, Communication interface**: DVPSM may be followed by numbers or alphabets.

**Power Supply Modules**: DVPPS02, DPS024-24V43, DPR20A, DVPPS05.

**Power modules**: Models AHPS05, AHPS15, followed by numbers, alphabets or blank.

**CPU unit**: Model AH, followed by CPU, followed by 500, 510, 520, 530, followed by RS, EN, followed by numbers, alphabets or blank.

**Digital IO unit**: Model AH, followed by 08, 16, 32, 64, followed by A through Z or 0 through 9, followed by M, N, P, R, followed by 00 through 99, followed by R, T, P, S, X, N, followed by A through Z or 0 through 9, followed by A, B, C, followed by numbers, alphabets or blank.

**Analog IO unit**: Model AH, followed by 01, 02, 04, 06, 08, 16, followed by AD, DA, XA, LC, followed by numbers, alphabets or blank.

**Various & communication IO units**: Model AH, followed by 01-30, followed by PT, TC, HC, PM, MC, EN, SCM, DNET, PFBM, PFBS, EIP, followed by numbers, alphabets or blank; Model AH, followed by RTU, followed by COPM, DNET, ETHN, PFBS, followed by numbers, alphabets or blank.

**Accessories: I/O extension for AH series**, Model AHBP, followed by numbers, alphabets or blank; **I/O extension for DI/DO units**, Model DVPAETB, followed by numbers, alphabets or blank.

Last Updated on 2012-09-18

[Questions?](#)

[Print this page](#)

[Terms of Use](#)

[Page Top](#)

◆ 2012 UL LLC

When the UL Leaf Mark is on the product, or when the word "Environment" is included in the UL Mark, please search the [UL Environment database](#) for additional information regarding this product's certification.

The appearance of a company's name or product in this database does not in itself assure that products so

identified have been manufactured under UL's Follow-Up Service. Only those products bearing the UL Mark should be considered to be Listed and covered under UL's Follow-Up Service. Always look for the Mark on the product.

UL permits the reproduction of the material contained in the Online Certification Directory subject to the following conditions: 1. The Guide Information, Designs and/or Listings (files) must be presented in their entirety and in a non-misleading manner, without any manipulation of the data (or drawings). 2. The statement "Reprinted from the Online Certifications Directory with permission from UL" must appear adjacent to the extracted material. In addition, the reprinted material must include a copyright notice in the following format: "© 2012 UL LLC".



## NRAQ7.E206327 Programmable Controllers Certified for Canada

[Page Bottom](#)

### Programmable Controllers Certified for Canada

[See General Information for Programmable Controllers Certified for Canada](#)

#### **DELTA ELECTRONICS INC**

E206327

31-1 SHIEN PAN RD  
KUEI SAN INDUSTRIAL ZONE  
TAOYUAN HSIEN, 333 TAIWAN

**Accessories, Communication interface:** DVP followed by CP, DT or PF, followed by 02, followed by H, maybe followed by additional suffixes or blank.

**Accessories; Temperature sensor:** DVP08TC-H, maybe followed by additional suffixes.

**Communication accessory device,** Model RTU-EN01.

**Communication interface units,** Models DNA02, COA02, DVPEN01-SL, DVPCOPM-SL, RTU-485, RTU-DNET, ENA01-MOD, ENA01-EIP, DVPPF02-SL, RTU-PD01.

Model DVS, followed by 005, 008 or 016, followed by any alphabets, numbers or blank.

Models DMV1000-80GX and keypad accessory DMV1000-KEY.

**Control modules,** DVP followed by 14, 16, 24, 30, 32, 20, 40 or 60, followed by ES, EX, SS or EC, may be followed by 2, followed by 00, 01, 10 or 11, followed by R, S or T, may be followed by additional suffixes.

DVP followed by 16, 20, 32, 40, 48, 60, 64 or 80, followed by EH, followed by 00, followed by R, T or M, may be followed by additional suffixes; DVP20PM00D, DVP20PM00M, DVP10PM00M may be followed by additional suffixes

DVP14SS11T, DVP14SS11R, DVP14SS11R2, DVP14SS11T2, DVP14SS11R.

DVP followed by 10 or 28, followed by SX or SV, followed by 11, followed by R or T; DVP followed by 12, 10 or 32, followed by SA, SC, MC or ES, may be followed by 2, followed by 11, followed by R, S, T or P, followed by additional suffixes or blank.

Models DVP12SE11R, DVP12SE11T followed by additional suffixes or blank.

ELC followed by PC, followed by 12, followed by N, followed by N, followed by A, followed by R; Model DVP12SA10R may be followed by additional suffixes.

Model DCH1000A.

DVP followed by 12, 14 or 20, followed by SS2 or SX2, followed by 11, followed by R, T or S, may be followed by additional suffix.

**Expansion I/O units,** DVP followed by 08, 14, 16, 24 or 32, followed by XM, XN or XP, may be followed by 2, followed by 00, 01 or 11, followed by R, N or T, may be followed by additional suffixes.

DVP followed by 02, 04, 06, followed by AD, DA, TC, XA or PT, followed by E2, may be followed by additional suffixes, rated 24V dc.

DVP followed by 08, 16, 32 or 48, followed by HN, HM or HP, Followed by 11 or 00, followed by R, T or N, may be followed by additional suffixes; DVP followed by 01 or 02, followed by HC, followed by -H, may be followed by additional suffixes; Models DVP01PU-H, DVP06XA-H may be followed by additional suffixes.

**Expansion modules,** DVP16SP11R, DVP16SP11T, DVP08SM11N, DVP08SN11R, DVP08SN11T, DVP08SP11R, DVP08SP11T.

DVP followed by 01, 04 or 06, followed by AD, DA, PT, PU, followed by -S; Modules DVP06XA-S, DVP02DA-S, DVP08RT-S, DVP04TC-S followed by additional suffixes or blank.

DVP followed by 06, 08, followed by SN, ST, followed by 11, followed by R, N, followed by additional suffixes or blank.

Model DVP10RC-E2 followed by additional suffixes or blank.

ELC followed by EX, followed by 08, followed by N, followed by N, followed by A, followed by N; Models

DVP08SM10N, ADP485-01, DVPDNET-SL, DVP16SM11N, DVP16SP11TS, DVP16SN11T, DVP32SM11N, DVP32SN11TN, DVP02LC-SL, DVP01LC-SL. Followed by additional suffixes or blank.

DVP followed by PF or DT, followed by 01, followed by -S, followed by additional suffixes or blank.

Model DOP followed by -EX, followed by IO, followed by 28 or 14, followed by R, followed by AE; Model DOP followed by -EX, followed by LN, followed by G, H or T, followed by J, followed by 1, 2 or 4, followed by AE.

**Expansion unit**, Model DVP, followed by 04, followed by DA or AD, followed by -SL.

**Hand held programmer**, DVPHPP0, followed by additional suffixes.

**Human machine interface**, Model DOP, followed by -B, followed by -07, -08 or -10, followed by S or E, followed by 41x, 411, 415, 515 or 615, may be followed by additional suffix.

Model HMC, followed by 08, followed by -, followed by A-Z, followed by 0-9, followed by 00-99, followed by S, followed by 0-6, followed by 0-6.

Models DOP-B03 followed by E or S, followed by 210 or 211, may be followed by additional suffixes.

**Power modules**, DVPPS01, DVPPS02.

**Programmable human machine interfaces**, Model TP followed by 02, 04, 05 or 08, followed by T or G, followed by A or B, followed by S, followed by 1 or 2; Models TP04G-AL-C, TP04G-BL-C.

Models TP followed by 04, followed by P, followed by 00-99, followed by TP, EX or XA, followed by additional alphanumeric letters or blank.

DOP followed by -A or -AE, followed by 57, followed by G, C or B, followed by STD, may be followed by -W; Models DOP-AS57BSTD, DOP-A75CSTD, DOP-AE80THTD, DOP-AE80THTD0, DOP-A10THTD1, DOP-AE10THTD, DOP-A10TCTD, DOP-AE10THTD1, DOP-AS38BSTD, DOP-AS38BSTD-W, DOP-B07S200, DOP-B05S100, DOP-B05S101, DOP-B07S201, DOPB07S201A, DOP-B07S211, DOP-AS35THTD and DOP-B07S411K.

Model DOP-NP3, followed by -MQ, followed by 0 through 9, followed by 0 or 1, followed by 0 or 1, may be followed by B.

Model DOP-NP5, followed by -MQ or -SQ, followed by 0 through 9, followed by 0 or 1, followed by 0 or 1, may be followed by B.

**Programmable logic controller**, Model DVP, followed by 10 through 60, followed by EC, followed by 00, followed by R or T, may be followed by additional suffix.

**Pressure sensor**, Model DPA01 or DPA10 may be followed by additional suffix.

**Accessories:** DPA-CBL, QPS-CBL.

**Listed Accessories, Communication interface:** DVPCSM may be followed by numbers or alphabets.

**Power Supply Modules:** DVPPS02, DPS024-24V43, DPR20A, DVPPS05.

**Power modules:** Models AHPS05, AHPS15, followed by numbers, alphabets or blank.

**CPU unit:** Model AH, followed by CPU, followed by 500, 510, 520, 530, followed by RS, EN, followed by numbers, alphabets or blank.

**Digital IO unit:** Model AH, followed by 08, 16, 32, 64, followed by A through Z or 0 through 9, followed by M, N, P, R, followed by 00 through 99, followed by R, T, P, S, X, N, followed by A through Z or 0 through 9, followed by A, B, C, followed by numbers, alphabets or blank.

**Analog IO unit:** Model AH, followed by 01, 02, 04, 06, 08, 16, followed by AD, DA, XA, LC, followed by numbers, alphabets or blank.

**Various & communication IO units:** Model AH, followed by 01-30, followed by PT, TC, HC, PM, MC, EN, SCM, DNET, PFBM, PFBS, EIP, followed by numbers, alphabets or blank; Model AH, followed by RTU, followed by COPM, DNET, ETHN, PFBS, followed by numbers, alphabets or blank.

**Accessories: I/O extension for AH series**, Model AHBP, followed by numbers, alphabets or blank; **I/O extension for DI/DO units**, Model DVPAETB, followed by numbers, alphabets or blank.

Last Updated on 2012-09-18

[Questions?](#)

[Print this page](#)

[Terms of Use](#)

[Page Top](#)

◆ 2012 UL LLC

When the UL Leaf Mark is on the product, or when the word "Environment" is included in the UL Mark, please search the [UL Environment database](#) for additional information regarding this product's certification.

The appearance of a company's name or product in this database does not in itself assure that products so identified have been manufactured under UL's Follow-Up Service. Only those products bearing the UL Mark should

be considered to be Listed and covered under UL's Follow-Up Service. Always look for the Mark on the product.

UL permits the reproduction of the material contained in the Online Certification Directory subject to the following conditions: 1. The Guide Information, Designs and/or Listings (files) must be presented in their entirety and in a non-misleading manner, without any manipulation of the data (or drawings). 2. The statement "Reprinted from the Online Certifications Directory with permission from UL" must appear adjacent to the extracted material. In addition, the reprinted material must include a copyright notice in the following format: "© 2012 UL LLC".